Original		Replacement	
	Power		Power
	Mute		Mute / Dimmer
	<<		<< / Tune-
	Zoom		Zoom / Size
	[I]		Display / Media
	[--]		Smart / List
	>>		>> / Tune+
	I<<		I<< / Preset-
	Play/Pause 2		Pause / Step / Freeze
	Play/Pause 1		Play / Slow
	>>I		>>I / Preset+
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	M		Menu / Home

Original		Replacement	
	S		AV / Input / RDS
	Back		Back / Return
	Vol-		Vol-
	Vol+		Vol+

https://remotecontrols.at/en/WiMiUS/1067574-96363-replacement-remote-control-for-WiMiUS-P20.html