Original		Replacement	
Power		Power	
Caption		Subtitle / EQ	
AV Mode		Text / Goto	
[ ]/Ratio		Display / Media	
Input		AV / Input / RDS	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
List		Shift + Smart / List	
0		0	
Flashbk		Zoom / Size	

Original		Replacement	
Vol +		Vol +	
FAV		Fav / Marker / PC	
CH+		CH+ / Page+	
Vol -		Vol -	
Info		Info / Angle	
CH-		CH- / Page-	
Mute		Mute / Dimmer	
Settings		Setup / OPT /	
Smart		Smart / List	
My APPS		Shift + Green / APP /	
Up		Up	
Left		Left	
OK		OK	
Right		Right	
Down		Down	
Back		Back / Return	
Q.Menu		D.Menu / Top	

Menu

Original		Replacement	Original	Replacement
EXIT	Exit	CLEAR EXIT CANCEL Exit / Cancel / Clear		
	Red	NETFLIX SEARCH Red / Netflix / Search		
	Green	APP REPEAT Green / APP / Repeat		
	yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM Blue / Prime Video / Random		
	Stop	HOLD Stop / Hold		
	Play	SLOW Play / Slow		
	Pause	STEP-FREEZE Pause / Step / Freeze		
	<<	TUNE- << / Tune-		
	>>	TUNE+ >> / Tune+		
SIMPLINK	Simplink	FORMAT PICTURE Picture / Format		
SLEEP	Sleep	TIMER SLEEP Sleep / Timer		
VD/*	VD/*	SURROUND Eject / Surround		
TV	TV	PROGRAM TV/RADIO TV/Radio /		