Original		Replacement	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
S.MODE	S. Mode	TITLE SOUND	Sound / Title
CAPTION	Caption	EQ SUBTITLE	Subtitle / EQ
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
P.SIZE	P. Size	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
DNSe	DNSe	OPT-TOOLS SETUP	Setup / OPT /
ANTENNA	Antenna	GOTO TEXT	Text / Goto
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home
	Up		Up

Original		Replacement	
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Ok		OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
PRE-CH	Pre-Ch	RETURN BACK	Back / Return
VOL	Vol +	VOL	Vol +
MTS	MTS	LIST SMART	Smart / List
CH	Ch+	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
	Ch-	CH PAGE	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Replacement		Original	Replacement
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
–	-	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
FAV.CH	Fav. Ch	PC FAV MARKER	Fav / Marker / PC		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
STILL	Still	SHIFT + STEP - FREEZE ⏸	Shift + Pause / Step /		
CH MGR	CH MGR	SHIFT + FORMAT PICTURE	Shift + Picture / Format		

Original		Replacement	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Ok	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
VOL	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -

Original		Replacement	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Replacement	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
P.SIZE	P. Size	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Ok	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
	Down		Down
PRE-CH	Pre-Ch	RETURN BACK	Back / Return
VOL	Vol +	+ VOL	Vol +
CH	Ch+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
	Ch-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
FAV.CH	Fav. Ch	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
POWER	Power CABLE		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play VCR	SLOW	Play / Slow
PLAY/PAUSE	Pause VCR	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop VCR	HOLD	Stop / Hold
REW	<< VCR	TUNE-	<< / Tune-
FF	>> VCR	TUNE+	>> / Tune+
	Ch- VCR	PRESET-	I<< / Preset-
CH	Ch+ VCR	PRESET+	>>I / Preset+
MENU	Menu VCR	HOME MENU	Menu / Home
	Up VCR		Up
INFO	Info VCR	ANGLE INFO	Info / Angle
	Left VCR		Left
ENTER	Ok VCR	OK	OK
	Right VCR		Right
EXIT	Exit VCR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down VCR		Down

Original		Replacement	
VOL	Vol +	+ VOL	Vol +
CH	Ch+ CABLE	+ CH PAGE	CH+ / Page+
	Vol -	VOL –	Vol -
	Ch- CABLE	CH PAGE –	CH- / Page-
1	1 CABLE	TV 1	1
2	2 CABLE	DVD 2	2
3	3 CABLE	CD-STB 3	3
4	4 CABLE	VIDEO 4	4
5	5 CABLE	TAPE 5	5
6	6 CABLE	TUNER 6	6
7	7 CABLE	AUX-HDD 7	7
8	8 CABLE	USB 8	8
9	9 CABLE	BLUETOOTH 9	9
0	0 CABLE	HDMI-SAT 0	0
POWER	Power VCR	SHIFT +	Shift + Power
1	1 VCR	SHIFT + TV 1	Shift + 1
2	2 VCR	SHIFT + DVD 2	Shift + 2

Original		Replacement		Original	Replacement
3	3 VCR	SHIFT + CD - STB 3	Shift + 3		
4	4 VCR	SHIFT + VIDEO 4	Shift + 4		
5	5 VCR	SHIFT + TAPE 5	Shift + 5		
6	6 VCR	SHIFT + TUNER 6	Shift + 6		
7	7 VCR	SHIFT + AUX - HDD 7	Shift + 7		
8	8 VCR	SHIFT + USB 8	Shift + 8		
9	9 VCR	SHIFT + BLUETOOTH 9	Shift + 9		
0	0 VCR	SHIFT + HDMI - SAT 0	Shift + 0		