Original	Replacement	Original	Replacement
Power	Power	Right	Right
Mute	Mute / Dimmer	Down	Down
Play	Play / Slow	Vol +	Vol +
Stop	Stop / Hold	[-O-] / Active Control	Smart / List
Rec	Rec / Rec Mode	P+	CH+ / Page+
<<	<< / Tune-	Vol -	Vol -
>>	>> / Tune+	P-	CH- / Page-
[<>]	Picture / Format	1	1
>I<	D.Menu / Top	2	2
[1I2]	Setup / OPT /	3	3
[≡]	Text / Goto	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i+]	Info / Angle	8	8
Left	Left	9	9
OK	OK	Guide	Guide / EPG / -/--

Original	Replacement	Original	Replacement
0	0	Vol + AMP	Shift + Vol +
P<P	Fav / Marker / PC	P+ AMP	Shift + CH+ /
Red	Red / Netflix / Search	Vol - AMP	Shift + Vol -
Green	Green / APP / Repeat	P- AMP	Shift + CH- /
Yellow	Yellow / YouTube / Repeat	1 AMP	Shift + 1
Blue	Blue / Prime Video / Random	2 AMP	Shift + 2
Power AMP	Shift + Power	3 AMP	Shift + 3
Mute AMP	Shift + Mute / Dimmer	4 AMP	Shift + 4
<< AMP	Shift + << /	5 AMP	Shift + 5
>> AMP	Shift + >> /	6 AMP	Shift + 6
[≡] AMP	Shift + Text /	7 AMP	Shift + 7
Menu AMP	Shift + Menu /	8 AMP	Shift + 8
Up AMP	Shift + Up	9 AMP	Shift + 9
Left AMP	Shift + Left	Guide AMP	Shift + Guide / EPG / -/--
OK AMP	Shift + OK	0 AMP	Shift + 0
Right AMP	Shift + Right	P<P AMP	Shift + Fav / Marker / PC
Down AMP	Shift + Down		

Original		Replacement		Original		Replacement	
	Power		Power		P-		CH- / Page-
	Guide		Guide / EPG / -/--		1		1
	Source		AV / Input / RDS		2		2
	>I<		D.Menu / Top		3		3
	[1I2]		Setup / OPT /		4		4
	[i+]		Info / Angle		5		5
	Up		Up		6		6
	Left		Left		7		7
	OK		OK		8		8
	Right		Right		9		9
	Down		Down		0		0
	[≡]		Text / Goto		P<P		Fav / Marker / PC
	Menu		Menu / Home		<<		<< / Tune-
	Vol +		Vol +		Stop		Stop / Hold
	Mute		Mute / Dimmer		Play		Play / Slow
	P+		CH+ / Page+		>>		>> / Tune+
	Vol -		Vol -		[<>]		Picture / Format

Original	Replacement	Original	Replacement
[-O-]/Active Control	Smart / List		

Original		Replacement		Original		Replacement	
	Power		Power		Down		Down
	Mute		Mute / Dimmer		Vol +		Vol +
	Play		Play / Slow		[-O-] / Active Control		Smart / List
	Stop		Stop / Hold		P+		CH+ / Page+
	Rec		Rec / Rec Mode		Vol -		Vol -
	<<		<< / Tune-		P-		CH- / Page-
	>>		>> / Tune+	1	1	1	1
	[<>]		Picture / Format	2	2	2	2
	>I<		D.Menu / Top	3	3	3	3
	[1I2]		Setup / OPT /	4	4	4	4
	Source		AV / Input / RDS	5	5	5	5
	Menu		Menu / Home	6	6	6	6
	Up		Up	7	7	7	7
	[i+]		Info / Angle	8	8	8	8
	Left		Left	9	9	9	9
OK	OK	OK	OK	0	0	0	0
	Right		Right	P<P	P<P		Fav / Marker / PC

Original	Replacement	Original	Replacement
Red	Red / Netflix / Search	Right VCR	Shift + Right
Green	Green / APP / Repeat	Down VCR	Shift + Down
Yellow	Yellow / YouTube / Repeat	P+ VCR	Shift + CH+ /
Blue	Blue / Prime Video / Random	P- VCR	Shift + CH- /
Power VCR	Shift + Power	1 VCR	Shift + 1
Play VCR	Shift + Play /	2 VCR	Shift + 2
Stop VCR	Shift + Stop /	3 VCR	Shift + 3
Rec VCR	Shift + Rec / Rec Mode	4 VCR	Shift + 4
<< VCR	Shift + << /	5 VCR	Shift + 5
>> VCR	Shift + >> /	6 VCR	Shift + 6
>I < VCR	Shift + D.Menu / Top Menu	7 VCR	Shift + 7
Source VCR	Shift + AV / Input / RDS	8 VCR	Shift + 8
Menu VCR	Shift + Menu /	9 VCR	Shift + 9
Up VCR	Shift + Up	0 VCR	Shift + 0
[i +] VCR	Shift + Info / Angle	P<P VCR	Shift + Fav / Marker / PC
Left VCR	Shift + Left		
OK VCR	Shift + OK		

Original		Replacement		Original		Replacement	
	Power		Power	5	5	TAPE 5	5
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--	6	6	TUNER 6	6
	>I<	TOP MENU D.MENU	D.Menu / Top	7	7	AUX - HDD 7	7
	[i+]	ANGLE INFO	Info / Angle	8	8	USB 8	8
	Up		Up	9	9	BLUETOOTH 9	9
	Left		Left	0	0	HDMI - SAT 0	0
	Right		Right	P<P	P<P	PC FAV MARKER	Fav / Marker / PC
	Down		Down	<<	<<	TUNE-	<< / Tune-
	Vol +	VOL	Vol +		Stop	HOLD	Stop / Hold
	Mute	DIMMER MUTE	Mute / Dimmer		Play	SLOW	Play / Slow
	P+	CH PAGE	CH+ / Page+	>>	>>	TUNE+	>> / Tune+
	Vol -	VOL	Vol -				
	P-	CH PAGE	CH- / Page-				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
4	4	VIDEO 4	4				