Original	Replacement	Original	Replacement
On/Off	Power	Progr/C/CH	TV/Radio /
Audio Out	Mute / Dimmer	PAL/Secam	D.Menu / Top
Play	Play / Slow	Sp/Lp/Speed	Setup / OPT /
Pause	Pause / Step / Freeze	Video/Go-To	Text / Goto
Stop	Stop / Hold	Input Source	AV / Input / RDS
Record	Rec / Rec Mode	Menu	Menu / Home
Rewind	<< / Tune-	Menu Up	Up
F.Forward	>> / Tune+	Info/Intro	Info / Angle
Prev.	I<< / Preset-	Menu Left	Left
Next	>>I / Preset+	OK Enter	OK
Mark Add/Del	Sound / Title	Menu Right	Right
Audio	Audio / Lang I/II	Exit	Exit / Cancel / Clear
Timer/Record	Subtitle / EQ	Menu Down	Down
Ch.Memo	Eject / Surround	Erase	Back / Return
Vps/Pdc	Picture / Format	Slow/Dpss+	Vol+
Case Tape	Zoom / Size	VCR/TV	Smart / List
Timer/Sleep	Sleep / Timer	Chan+	CH+ / Page+



Original	Replacement	Original	Replacement
Slow/Dpss-	VOL – Vol-	Rec. On/Off	YouTube REPEAT A-B Yellow / YouTube / Repeat
Display	MEDIA DISPLAY Display / Media	Otr/A.Otr	Prime Video RANDOM Blue / Prime Video / Random
Chan-	CH PAGE – CH- / Page-	On/Off	SHIFT + Power Shift + Power
1	TV 1 1	Store	SHIFT + SLOW Shift + Play /
2	DVD 2 2	Counter Clock	SHIFT + STEP - FREEZE Shift + Pause / Step /
3	CD - STB 3 3	Counter/Memor	SHIFT + HOLD Shift + Stop /
4	VIDEO 4 4	Search Index	SHIFT + REC MODE Shift + Rec / Rec Mode
5	TAPE 5 5	Next Sv+V	SHIFT + PRESET+ Shift + >>I / Preset+
6	TUNER 6 6	T.Set/Clock	SHIFT + GOTO TEXT Shift + Text /
7	AUX - HDD 7 7	Frame Up	SHIFT + Shift + Up
8	USB 8 8	Clear 00:00	SHIFT + CLEAR EXIT CANCEL Shift + Exit / Cancel / Clear
9	BLUETOOTH 9 9	Frame Down	SHIFT + Shift + Down
-/--	-/-- GUIDE EPG Guide / EPG / -/--	Auto/Track	SHIFT + LIST SMART Shift + Smart / List
0	HDMI - SAT 0 0	Count Remain	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC
Syst.	PC FAV MARKER Fav / Marker / PC	Once	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /
Skip/Search	NETFLIX SEARCH Red / Netflix / Search	Daily	SHIFT + APP REPEAT Shift + Green / APP /
Repeat	APP REPEAT Green / APP / Repeat	Weekly	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube / Repeat



Original	Replacement	Original	Replacement
Rec/Mode	SHIFT + Prime Video RANDOM Shift + Blue / Prime		

