Original	Replacement	Original	Replacement
Open/Close	Eject / Surround	Title	Sound / Title
OSD	Display / Media	Left	Left
Standby/On	Power	Enter	OK
1	1	Right	Right
2	2	Zoom	Zoom / Size
3	3	Down	Down
4	4	Menu	Menu / Home
5	5	<<	<< / Tune-
6	6	>>	>> / Tune+
7	7	I <<	I << / Preset-
8	8	>>I	>>I / Preset+
9	9	Stop	Stop / Hold
+10	Guide / EPG / -/--	Play/Pause	Play / Slow
0/10	0	II >/Step	Pause / Step / Freeze
Goto	Text / Goto	Ran	Blue / Prime Video / Random
Setup	Setup / OPT /	I >/Slow	Picture / Format
Up	Up	Vol -	Vol -

Original	Replacement	Original	Replacement
Vol +	Vol +		
Subtitle	Subtitle / EQ		
Audio	Audio / Lang I/II		
Angle	Info / Angle		
Video	Shift + 4		
PBC	D. Menu / Top		
Prog	TV/ Radio /		
RL	CH+ / Page+		
NP	CH- / Page-		
Repeat	Green / APP / Repeat		
A-B	Yellow / YouTube / Repeat		
Return	Back / Return		
Mute	Mute / Dimmer		