Original		Replacement	
POWER	Power	POWER	Power
INFO	Info	ANGLE INFO	Info / Angle
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0
AUDIO	O)/I-II/Audi c	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
CH+	CH+	+ CH PAGE	CH+ / Page+
INDEX	Index	MEDIA DISPLAY	Display / Media
VOL+	Vol +	+ VOL	Vol +
CH-	CH-	CH PAGE −	CH- / Page-
LIST	List	LIST SMART	Smart / List
VOL-	Vol -	VOL −	Vol -
♥	♥	PC FAV MARKER	Fav / Marker / PC
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
↩	Recall	RETURN BACK	Back / Return
	Red	NETFLIX SEARCH	Red / Netflix / Search
<<	<<	TUNE- ◀◀	<< / Tune-

Original	Replacement	Original	Replacement
Green	Green / APP / Repeat		
>>	>> / Tune+		
Yellow	Yellow / YouTube / Repeat		
I <<	I << / Preset-		
Blue	Blue / Prime Video / Random		
>>I	>>I / Preset+		
[≡]	Text / Goto		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
[≡+]	Zoom / Size		
Stop/Still	Stop / Hold		
Radio	TV/Radio /		
[≡♦] / [++]	Setup / OPT /		
[≡x]	Picture / Format		
[≡o] / Subtitle	Subtitle / EQ		
DMP	D. Menu / Top		
Rec	Rec / Rec Mode		

Original	Replacement	Original	Replacement
Power	Power	Left	Left
Mute	Mute / Dimmer	Enter	OK
Text / Play/Paus	Play / Slow	Right	Right
Text / Play/Paus	Pause / Step / Freeze	Exit	Exit / Cancel / Clear
Stop / Still	Stop / Hold	Down	Down
Rec	Rec / Rec Mode	Recall	Back / Return
Audio I/II	Audio / Lang I/II	Vol +	Vol +
Subtitle / [≡o]	Subtitle / EQ	List	Smart / List
[≡x]	Picture / Format	CH +	CH+ / Page+
Size / Aspect	Zoom / Size	Vol -	Vol -
Sleep	Sleep / Timer	Index	Display / Media
Radio	TV/ Radio /	CH -	CH- / Page-
DMP	D. Menu / Top	1	1
Source	AV / Input / RDS	2	2
Menu	Menu / Home	3	3
Up	Up	4	4
Info	Info / Angle	5	5

Original		Replacement		Original	Replacement
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
▼	Fav	PC FAV MARKER	Fav / Marker / PC		
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search		
	Green / >>	APP REPEAT	Green / APP / Repeat		
	Yellow / I <<	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue / >>I	Prime Video RANDOM	Blue / Prime Video / Random		
	Text / Play/Paus	SHIFT + SLOW ▶	Shift + Play /		
	Red / <<	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /		
	Green / >>	SHIFT + APP REPEAT	Shift + Green / APP /		
	Yellow / I <<	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /		
	Blue / >>I	SHIFT + Prime Video RANDOM	Shift + Blue / Prime		