Original	Replacement
POWER	Power
←○	SHIFT + SMART — Shift + Smart / List
☼*/Ö	SHIFT + DISPLAY — Shift + Display / Media
☼²/♀	SHIFT + NETFLIX SEARCH — Shift + Red / Netflix /
SOURCE	RDS AV INPUT — AV / Input / RDS
PRESETS	LIST SMART — Smart / List
┼┼┼	OPT-TOOLS SETUP — Setup / OPT /
♫/☺◘	MEDIA DISPLAY — Display / Media
SLEEP	TIMER SLEEP — Sleep / Timer
1 . /@	TV 1 — 1
2 abc	DVD 2 — 2
3 def	CD - STB 3 — 3
4 ghi	VIDEO 4 — 4
5 jkl	TAPE 5 — 5
6 mno	TUNER 6 — 6
7 pqrs	AUX - HDD 7 — 7
8 tuv	USB 8 — 8

Original	Replacement
9 wxyz	BLUETOOTH 9 — 9
TV	PROGRAM TV/RADIO — TV/Radio /
0	HDMI - SAT 0 — 0
↔	SHIFT + RETURN BACK — Shift + Back / Return
TV GUIDE	-/-- GUIDE EPG — Guide / EPG / -/--
[≡]	GOTO TEXT — Text / Goto
MENU	HOME MENU — Menu / Home
Q. MENU	TOP MENU D.MENU — D. Menu / Top
UP	Up
LEFT	Left
OK	OK — OK
RIGHT	Right
DOWN	Down
BACK	RETURN BACK — Back / Return
⊸◉⊸	FORMAT PICTURE — Picture / Format
EXIT	CLEAR EXIT CANCEL — Exit / Cancel / Clear
☼FAV	PC FAV MARKER — Fav / Marker / PC

Original	Replacement
VOL+	Vol +
MUTE	Mute / Dimmer
P+	CH+ / Page+
VOL-	Vol -
INFO	Info / Angle
P-	CH- / Page-
REC	Rec / Rec Mode
PLAY	Play / Slow
PAUSE	Pause / Step / Freeze
STOP	Stop / Hold
LANG.	Audio / Lang I/II
<<	<< / Tune-
>>	>> / Tune+
[≡]...	Sound / Title
RED	Red / Netflix / Search
GREEN	Green / APP / Repeat
YELLOW	Yellow / YouTube / Repeat

Original	Replacement
BLUE	Blue / Prime Video / Random