Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	TV Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
Bluetooth	Bluetooth	SHIFT + BLUETOOTH 9	Shift + 9
GAME	Game	SHIFT + TAPE 5	Shift + 5
AUX2	AUX2	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PHONO	Phono	PC FAV MARKER	Fav / Marker / PC
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media
CD	CD	SHIFT + CD - STB 3	Shift + 3
ONLINE MUSIC	Online Music	LIST SMART	Smart / List
INTERNET RADIO	Internet Radio	-/-- GUIDE EPG	Guide / EPG / -/--
1	Quick Select 1	TITLE SOUND	Sound / Title

Original		Replacement	
2	Quick Select 2	LANG I/II AUDIO	Audio / Lang I/II
3	Quick Select 3	EQ SUBTITLE	Subtitle / EQ
4	Quick Select 4	SURROUND	Eject / Surround
CH/PAGE	CH/Page Up	CH PAGE +	CH+ / Page+
ECO	Eco	GOTO TEXT	Text / Goto
VOLUME	Volume+	VOL +	Vol +
	CH/Page Down	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Volume-	VOL –	Vol -
INFO	Info	ANGLE INFO	Info / Angle
	Up		Up
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down

Original		Replacement		Original		Replacement	
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /	SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TUNE –	I<</ Tune-	PRESET-	I<< / Preset-	GHI 4	4	VIDEO 4	4
TUNE –	I<</ Tune-	SHIFT + TUNE-	Shift + << /	JKL 5	5	TAPE 5	5
▶	Play	SLOW ▶	Play / Slow	MNO 6	6	TUNER 6	6
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+	PQRS 7	7	AUX-HDD 7	7
TUNE +	>>I / Tune+	SHIFT + TUNE+	Shift + >> /	TUV 8	8	USB 8	8
◀◀	<<	TUNE- ◀◀	<< / Tune-	WXYZ 9	9	BLUETOOTH 9	9
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze	0	0	HDMI-SAT 0	0
■	Stop	HOLD ■	Stop / Hold				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
MOVIE	Green/Movie	APP REPEAT	Green / APP / Repeat				
MUSIC	Red/Music	NETFLIX SEARCH	Red / Netflix / Search				
GAME	Blue/Game	Prime Video RANDOM	Blue / Prime Video / Random				
PURE	Yellow/Pure	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
. / 1	1	TV 1	1				
ABC 2	2	DVD 2	2				
DEF 3	3	CD-STB 3	3				

Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	TV Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
Bluetooth	Bluetooth	SHIFT + BLUETOOTH 9	Shift + 9
GAME	Game	SHIFT + TAPE 5	Shift + 5
AUX2	AUX2	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PHONO	Phono	PC FAV MARKER	Fav / Marker / PC
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media
CD	CD	SHIFT + CD - STB 3	Shift + 3
ONLINE MUSIC	Online Music	LIST SMART	Smart / List
INTERNET RADIO	Internet Radio	-/-- GUIDE EPG	Guide / EPG / -/--
1	Quick Select 1	TITLE SOUND	Sound / Title

Original		Replacement	
2	Quick Select 2	LANG I/II AUDIO	Audio / Lang I/II
3	Quick Select 3	EQ SUBTITLE	Subtitle / EQ
4	Quick Select 4	SURROUND	Eject / Surround
CH/PAGE	CH/Page Up	CH PAGE +	CH+ / Page+
VOLUME	Volume+	VOL +	Vol +
	CH/Page Down	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Volume-	VOL –	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<<Tune-	SHIFT + TUNE- <<	Shift + << /
TUNE –	I<<Tune-	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow

Original		Replacement		Original	Replacement
TUNE +	>>I / Tune+	PRESET+	>>I / Preset +		
TUNE +	>>I / Tune+	SHIFT + TUNE+	Shift + >> /		
	<<	TUNE-	<< / Tune-		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Stop	HOLD	Stop / Hold		
	>>	TUNE+	>> / Tune+		
1	1	TV 1	1		
ABC 2	2	DVD 2	2		
DEF 3	3	CD-STB 3	3		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
GHI 4	4	VIDEO 4	4		
JKL 5	5	TAPE 5	5		
MNO 6	6	TUNER 6	6		
PQRS 7	7	AUX-HDD 7	7		
TUV 8	8	USB 8	8		
WXYZ 9	9	BLUETOOTH 9	9		
0	0	HDMI-SAT 0	0		

Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	TV Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
Bluetooth	Bluetooth	SHIFT + BLUETOOTH 9	Shift + 9
GAME	Game	SHIFT + TAPE 5	Shift + 5
AUX2	AUX2	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PHONO	Phono	PC FAV MARKER	Fav / Marker / PC
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media
CD	CD	SHIFT + CD - STB 3	Shift + 3
ONLINE MUSIC	Online Music	LIST SMART	Smart / List
INTERNET RADIO	Internet Radio	-/-- GUIDE EPG	Guide / EPG / -/--
1	Quick Select 1	TITLE SOUND	Sound / Title

Original		Replacement	
2	Quick Select 2	LANG I/II AUDIO	Audio / Lang I/II
3	Quick Select 3	EQ SUBTITLE	Subtitle / EQ
4	Quick Select 4	SURROUND	Eject / Surround
CH/PAGE	CH/Page Up	CH PAGE +	CH+ / Page+
VOLUME	Volume+	VOL +	Vol +
	CH/Page Down	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Volume-	VOL –	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<</Tune-	SHIFT + TUNE- <<	Shift + << /
TUNE –	I<</Tune-	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow

Original		Replacement		Original	Replacement
TUNE +	>>I / Tune+	SHIFT + TUNE+	Shift + >> /		
TUNE +	>>I / Tune+	PRESET+	>>I / Preset +		
	<<	TUNE-	<< / Tune-		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Stop	HOLD	Stop / Hold		
	>>	TUNE+	>> / Tune+		
1	1	TV 1	1		
ABC 2	2	DVD 2	2		
DEF 3	3	CD-STB 3	3		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
GHI 4	4	VIDEO 4	4		
JKL 5	5	TAPE 5	5		
MNO 6	6	TUNER 6	6		
PQRS 7	7	AUX-HDD 7	7		
TUV 8	8	USB 8	8		
WXYZ 9	9	BLUETOOTH 9	9		
0	0	HDMI-SAT 0	0		