Mandis shop

TW6

Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
iPod MENU	iPod Menu	HOME MENU	Menu / Home
MENU	Menu Up		Up
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
PREV	I<<	PRESET-	I<< / Preset-
ENTER	Enter	OK	OK
NEXT	>>I	PRESET+	>>I / Preset+
MEM TIME	Mem Time	PROGRAM TV/ RADIO	TV/Radio /
MENU	Menu Down		Down
	Play / Pause	SLOW	Play / Slow
TREBLE	Treble +	CH PAGE	CH+ / Page+
BASS	Bass +		Right
VOLUME	Volume +	VOL	Vol+
TREBLE	Treble -	CH PAGE	CH- / Page-
BASS	Bass -		Left

Original		Replacement	
VOLUME	Volume -	VOL	Vol-

https://remotecontrols.at/en/1059499-85021-replacement-remote-control-for-TW6.html