Original		Replacement	
STANDBY	Standby	SHIFT + Power	Shift + Power
ON	On	Power	Power
1	ID 1	NETFLIX SEARCH	Red / Netflix / Search
2	ID 2	APP REPEAT	Green / APP / Repeat
3	ID 3	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	ID 4	Prime Video RANDOM	Blue / Prime Video / Random
COM PUTER 1	Computer 1	TV 1	1
COM PUTER 2	Computer 2	DVD 2	2
COM PUTER 3	Computer 3	CD - STB 3	3
LAN	LAN	TUNER 6	6
USB TYPE A	USB Type A	AUX - HDD 7	7
USB TYPE B	USB Type B	USB 8	8
COM PONENT	Component	BLUETOOTH 9	9
S-VIDEO	S. Video	TAPE 5	5
VIDEO	Video	VIDEO 4	4
HDMI 1	HDMI 1	-/-- GUIDE EPG	Guide / EPG / -/--
HDMI 2	HDMI 2	HDMI - SAT 0	0

Original		Replacement	
DIGITAL	Digital	PC FAV MARKER	Fav / Marker / PC
PAGE UP	Page Up	CH PAGE +	CH+ / Page+
ON MAGNIFY	Magnify On	LIST SMART	Smart / List
VOL +	Vol +	VOL +	Vol +
PAGE DOWN	Page Down	CH PAGE -	CH- / Page-
MAGNIFY OFF	Magnify Off	MEDIA DISPLAY	Display / Media
VOL -	Vol -	VOL -	Vol -
FREEZE	Freeze	STEP - FREEZE	Pause / Step / Freeze
F5	F5	SHIFT + TAPE 5	Shift + 5
AV MUTE	AV Mute	DIMMER MUTE	Mute / Dimmer
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
RESET	Reset	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home

Original		Replacement		Original		Replacement
ESC	ESC	CLEAR EXIT CANCEL	Exit / Cancel / Clear			
PbyP	PbyP	TOP MENU D.MENU	D. Menu / Top			
ASPECT	Aspect	FORMAT PICTURE	Picture / Format			
AUTO	Auto	OPT-TOOLS SETUP	Setup / OPT /			
1	My Button 1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /			
MY B 2	My Button 2	SHIFT + APP REPEAT	Shift + Green / APP /			
UTTON 3	My Button 3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /			
4	My Button 4	SHIFT + Prime Video RANDOM	Shift + Blue / Prime			
POSITION	Position	SURROUND	Eject / Surround			
LENS SHIFT	Lens Shift	PROGRAM TV/ RADIO	TV/ Radio /			
+ FOCUS	Focus +	PRESET+	>>I / Preset+			
+ ZOOM	Zoom +	TUNE+	>> / Tune+			
KEYSTONE	Keystone	RDS AV INPUT	AV / Input / RDS			
LENS MEMORY	Lens Memory	ANGLE INFO	Info / Angle			
FOCUS –	Focus -	PRESET-	I<< / Preset-			
ZOOM –	Zoom -	TUNE-	<< / Tune-			

Original		Replacement	
STANDBY	Standby	SHIFT + Power	Shift + Power
ON	On	Power	
1	ID 1	NETFLIX SEARCH	Red / Netflix / Search
2	ID 2	APP REPEAT	Green / APP / Repeat
3	ID 3	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	ID 4	Prime Video RANDOM	Blue / Prime Video / Random
COM PUTER 1	Computer 1	TV 1	1
COM PUTER 2	Computer 2	DVD 2	2
COM PUTER 3	Computer 3	CD - STB 3	3
LAN	LAN	TUNER 6	6
USB TYPE A	USB Type A	AUX - HDD 7	7
USB TYPE B	USB Type B	USB 8	8
COM PONENT	Component	BLUETOOTH 9	9
S-VIDEO	S. Video	TAPE 5	5
VIDEO	Video	VIDEO 4	4
HDMI 1	HDMI 1	-/-- GUIDE EPG	Guide / EPG / -/--
HDMI 2	HDMI 2	HDMI - SAT 0	0

Original		Replacement	
DIGITAL	Digital	PC FAV MARKER	Fav / Marker / PC
PAGE UP	Page Up	CH PAGE +	CH+ / Page+
ON MAGNIFY	Magnify On	LIST SMART	Smart / List
VOL +	Vol +	VOL +	Vol +
PAGE DOWN	Page Down	CH PAGE -	CH- / Page-
MAGNIFY OFF	Magnify Off	MEDIA DISPLAY	Display / Media
VOL -	Vol -	VOL -	Vol -
FREEZE	Freeze	STEP - FREEZE	Pause / Step / Freeze
F5	F5	SHIFT + TAPE 5	Shift + 5
AV MUTE	AV Mute	DIMMER MUTE	Mute / Dimmer
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
RESET	Reset	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home

Original		Replacement		Original	Replacement
ESC	ESC	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
PbyP	PbyP	TOP MENU D.MENU	D. Menu / Top		
ASPECT	Aspect	FORMAT PICTURE	Picture / Format		
AUTO	Auto	OPT-TOOLS SETUP	Setup / OPT /		
1	My Button 1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /		
MY B 2	My Button 2	SHIFT + APP REPEAT	Shift + Green / APP /		
UTTON 3	My Button 3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /		
4	My Button 4	SHIFT + Prime Video RANDOM	Shift + Blue / Prime		
POSITION	Position	SURROUND	Eject / Surround		
LENS SHIFT	Lens Shift	PROGRAM TV/ RADIO	TV/ Radio /		
+ FOCUS	Focus +	PRESET+	>>I / Preset+		
+ ZOOM	Zoom +	TUNE+	>> / Tune+		
KEYSTONE	Keystone	RDS AV INPUT	AV / Input / RDS		
LENS MEMORY	Lens Memory	ANGLE INFO	Info / Angle		
FOCUS −	Focus -	PRESET-	I<< / Preset-		
ZOOM −	Zoom -	TUNE-	<< / Tune-		

Original		Replacement	
STANDBY	Standby	SHIFT + Power	Shift + Power
ON	On	Power	
1	ID 1	NETFLIX SEARCH	Red / Netflix / Search
2	ID 2	APP REPEAT	Green / APP / Repeat
3	ID 3	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	ID 4	Prime Video RANDOM	Blue / Prime Video / Random
COM PUTER 1	Computer 1	TV 1	1
COM PUTER 2	Computer 2	DVD 2	2
COM PUTER 3	Computer 3	CD - STB 3	3
LAN	LAN	TUNER 6	6
USB TYPE A	USB Type A	AUX - HDD 7	7
USB TYPE B	USB Type B	USB 8	8
COM PONENT	Component	BLUETOOTH 9	9
S-VIDEO	S. Video	TAPE 5	5
VIDEO	Video	VIDEO 4	4
HDMI 1	HDMI 1	-/-- GUIDE EPG	Guide / EPG / -/--
HDMI 2	HDMI 2	HDMI - SAT 0	0

Original		Replacement	
DIGITAL	Digital	PC FAV MARKER	Fav / Marker / PC
PAGE UP	Page Up	CH PAGE +	CH+ / Page+
ON MAGNIFY	Magnify On	LIST SMART	Smart / List
VOL +	Vol +	VOL +	Vol +
PAGE DOWN	Page Down	CH PAGE -	CH- / Page-
MAGNIFY OFF	Magnify Off	MEDIA DISPLAY	Display / Media
VOL -	Vol -	VOL -	Vol -
FREEZE	Freeze	STEP - FREEZE	Pause / Step / Freeze
F5	F5	SHIFT + TAPE 5	Shift + 5
AV MUTE	AV Mute	DIMMER MUTE	Mute / Dimmer
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
RESET	Reset	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home

Original		Replacement		Original	Replacement
ESC	ESC	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
PbyP	PbyP	TOP MENU D.MENU	D. Menu / Top		
ASPECT	Aspect	FORMAT PICTURE	Picture / Format		
AUTO	Auto	OPT-TOOLS SETUP	Setup / OPT /		
1	My Button 1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /		
MY B 2	My Button 2	SHIFT + APP REPEAT	Shift + Green / APP /		
UTTON 3	My Button 3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /		
4	My Button 4	SHIFT + Prime Video RANDOM	Shift + Blue / Prime		
POSITION	Position	SURROUND	Eject / Surround		
LENS SHIFT	Lens Shift	PROGRAM TV/ RADIO	TV/ Radio /		
+ FOCUS	Focus +	PRESET+	>>I / Preset+		
+ ZOOM	Zoom +	TUNE+	>> / Tune+		
KEYSTONE	Keystone	RDS AV INPUT	AV / Input / RDS		
LENS MEMORY	Lens Memory	ANGLE INFO	Info / Angle		
FOCUS –	Focus -	PRESET-	I << / Preset-		
ZOOM –	Zoom -	TUNE-	<< / Tune-		

Original	Replacement	Original	Replacement
Standby	SHIFT + Shift + Power	Digital	Fav / Marker / PC
On	Power	Page Up	CH+ / Page+
ID 1	Red / Netflix / Search	Magnify On	Smart / List
ID 2	Green / APP / Repeat	Vol +	Vol +
ID 3	Yellow / YouTube / Repeat	Page Down	CH- / Page-
ID 4	Blue / Prime Video / Random	Magnify Off	Display / Media
Computer 1	1	Vol -	Vol -
Computer 2	2	Freeze	Pause / Step / Freeze
Computer 3	3	F5	SHIFT + TAPE 5 Shift + 5
LAN	6	AV Mute	Mute / Dimmer
USB Type A	7	Up	Up
USB Type B	8	Left	Left
Component	9	Enter	OK
S. Video	5	Right	Right
Video	4	Down	Down
HDMI 1	Guide / EPG / -/--	Reset	Back / Return
HDMI 2	0	Menu	Menu / Home

Original		Replacement		Original		Replacement
ESC	ESC	CLEAR EXIT CANCEL	Exit / Cancel / Clear			
PbyP	PbyP	TOP MENU D.MENU	D. Menu / Top			
ASPECT	Aspect	FORMAT PICTURE	Picture / Format			
AUTO	Auto	OPT-TOOLS SETUP	Setup / OPT /			
1	My Button 1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /			
MY B 2	My Button 2	SHIFT + APP REPEAT	Shift + Green / APP /			
UTTON 3	My Button 3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /			
4	My Button 4	SHIFT + Prime Video RANDOM	Shift + Blue / Prime			
POSITION	Position	SURROUND	Eject / Surround			
LENS SHIFT	Lens Shift	PROGRAM TV/ RADIO	TV/ Radio /			
+ FOCUS	Focus +	PRESET+	>>I / Preset+			
+ ZOOM	Zoom +	TUNE+	>> / Tune+			
KEYSTONE	Keystone	RDS AV INPUT	AV / Input / RDS			
LENS MEMORY	Lens Memory	ANGLE INFO	Info / Angle			
FOCUS −	Focus -	PRESET-	I<< / Preset-			
ZOOM −	Zoom -	TUNE-	<< / Tune-			