Mandis shop

LG 6710CMAM08D

Original		Replacement	
POWER	Power		Power
PRESET	Preset Up	CH +	Ch +
	Preset Down	CH –	Ch -
AUX	AUX	HOME SMART	Smart
TUNER/BAND	Tuner / Band	APP MEDIA	Media
VOLUME	Vol +	VOL +	Vol +
	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
SLEEP	Sleep	PROG SLEEP	Sleep
PROGRAM	Program	SHIFT + PROG SLEEP	Shift + Sleep
D.SKIP	D. Skip	ECO 3D	3D
▶/II	Play/Pause	II	Pause
■	Stop	■	Stop
▶▶I / >>I	>>I / >>I	>>I	>>I
I<< / <<	I<< / <<	I<<	I<<
REPEAT	Repeat	REPEAT TEXT	Text
▶	Play Tape	PLAY MODE ▶	Play

Original		Replacement	
◀◀	<< Tape	<<	<<
▶▶	>> Tape	>>	>>
TAPE – 2	Tape 2	B	Green
1 – TAPE	Tape 1	A	Red
●/II	Rec/Pause Tape	REC MODE ●	Rec
■	Stop Tape	SHIFT + ■	Shift + Stop
EQ PATT.	EQ PATT.	SOUND DUAL	Dual
XDSS	XDSS	AD SUBT	Subt
SURR.	Surr.	TIMER AV	AV
MP3 Info	MP3 Info	DISPLAY INFO	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Replacement	
8	8	8	8
9	9	9	9
0	0	0	0

Original	Replacement