Mandis shop

# LG AKB73616006

| Original | Replacement |
|---|---|
| Start | Power |
| Home | Menu / Home |
| Mode | Setup / OPT / |
| Turbo | Smart / List |
| Up | Up |
| Left | Left |
| Stop/OK | OK |
| Stop/OK | Stop / Hold |
| Right | Right |
| Down | Down |
| Repeat | Green / APP / Repeat |
| My Space | Display / Media |
| Nothing 1 | 1 |
| Mute | Mute / Dimmer |
| Nothing 2 | 2 |
| Diagnosis | D.Menu / Top |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://remotecontrols.at/en/LG/1068089-77844-replacement-remote-control-for-LG-AKB73616006.html