Original		Replacement	
SOUND MODE	Sound Mode	SOUND DUAL	Dual
PHONO	Phono	1	1
BALANCED	Balanced	2	2
CD	CD	3	3
RECORD 1	Record 1	4	4
RECORD 2	Record 2	7	7
LINE 1	Line 1	6	6
LINE 2	Line 2	9	9
TRIM	Trim	-/-- GUIDE	Guide
EXIT	Exit	CLEAR EXIT	Exit
TONE	Tone	SETTINGS OPT	Options
DISPLAY	Display	DISPLAY INFO	Info
ATT	ATT	AD SUBT	Subt
+	Up/+	▲	Up
-	Down/-	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left

Original		Replacement	
ENTER	Enter	OK	Ok
VOLUME ▲	Vol +	+ VOL	Vol +
VOLUME ▼	Vol -	VOL −	Vol -
⏮	I <<	⏮	I <<
⏭	>>I	⏭	>>I
◀◀	<<	◀◀	<<
▶▶	>>	▶▶	>>
SCAN	Scan	SEARCH TV/R	TV/R
TOP MENU AM/A	Top Menu/AM/A	SHIFT + TOP MENU MENU	Shift + Menu
RETURN FM/B	Return/FM/B	RETURN BACK	Back
MENU ◀▶	Menu/<>	TOP MENU MENU	Menu

Original		Replacement	
OPEN/CLOSE	Open/Close CD	ZOOM	Eject
SOUND MODE	Sound Mode CD	SOUND DUAL	Dual
EXIT	Exit CD	CLEAR EXIT	Exit
ENTER	Enter CD	OK	Ok
	Right CD		Right
	Left CD		Left
	Up/+ CD		Up
	Down/- CD		Down
PHONO	Phono	1	1
BALANCED	Balanced	2	2
CD	CD	3	3
RECORD 1	Record 1	4	4
RECORD 2	Record 2	7	7
LINE 1	Line 1	6	6
LINE 2	Line 2	9	9
TRIM	Trim	-/-- GUIDE	Guide
TONE	Tone	SETTINGS OPT	Options

Original		Replacement	
DISPLAY	Display	DISPLAY INFO	Info
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
	I<< CD		I<<
	Play CD	PLAY MODE	Play
	>>I CD		>>I
	<< CD		<<
	Pause CD		Pause
	>> CD		>>
	Stop CD		Stop
MENU	Menu/<> CD	TOP MENU MENU	Menu
RANDOM	Random CD	APP MEDIA	Media
REPEAT	Repeat CD	REPEAT TEXT	Text
SCAN	Scan CD	SEARCH TV/R	TV/R
ATT	ATT	AD SUBT	Subt
OPEN/CLOSE	Open/Close	SHIFT + ZOOM	Shift + Eject
	Up/+ Record 1	SHIFT +	Shift + Up

Original	Replacement	Original	Replacement
Down/ - Record	SHIFT + Down		
Right Record 1	SHIFT + Right		
Left Record 1	SHIFT + Left		
Enter Record 1	SHIFT + OK		
Random Record	SHIFT + MEDIA		
Scan Record 1	SHIFT + TV/R		
Repeat Record	SHIFT + TEXT		
Menu/ <> Record	SHIFT + MENU		
Stop Record 1	SHIFT + Stop		
Pause Record 1	SHIFT + Pause		
>>I Record 1	SHIFT + >>I		
I << Record 1	SHIFT + I <<		
<< Record 1	SHIFT + <<		
>> Record 1	SHIFT + >>		
Play Record 1	SHIFT + Play		

Original		Replacement	
SOUND MODE	Sound Mode	SOUND DUAL	Dual
OPEN/CLOSE	Open/Close	ZOOM ⏏	Eject
PHONO	Phono	1	1
BALANCED	Balanced	2	2
CD	CD	3	3
RECORD 1	Record 1	4	4
RECORD 2	Record 2	7	7
LINE 1	Line 1	6	6
LINE 2	Line 2	9	9
TRIM	Trim	-/-- GUIDE	Guide
EXIT	Exit	CLEAR EXIT	Exit
TONE	Tone	SETTINGS OPT	Options
DISPLAY	Display	DISPLAY INFO	Info
ATT	ATT	AD SUBT	Subt
+ ▲	Up/+	▲	Up
▼ −	Down/-	▼	Down
▶	Right	▶	Right

Original		Replacement	
◀	Left	◀	Left
ENTER	Enter	OK	Ok
▲ VOLUME	Vol +	+ VOL	Vol +
VOLUME ▼	Vol -	VOL −	Vol -
⏮	I <<	⏮	I <<
▶	Play	PLAY MODE ▶	Play
⏭	>>I	⏭	>>I
<<	<<	<<	<<
⏸	Pause	⏸	Pause
>>	>>	>>	>>
■	Stop	■	Stop
RANDOM	Random	APP MEDIA	Media
SCAN	Scan	SEARCH TV/R	TV/R
REPEAT	Repeat	REPEAT TEXT	Text
TOP MENU AM/A	Top Menu/AM/A	SHIFT + TOP MENU MENU	Shift + Menu
RETURN FM/B	Return/FM/B	RETURN BACK	Back
MENU ◀▶	Menu/<>	TOP MENU MENU	Menu

Original		Replacement	
SOUND MODE	Sound Mode	SOUND DUAL	Dual
OPEN/CLOSE	Open/Close	ZOOM ⏏	Eject
PHONO	Phono	1	1
BALANCED	Balanced	2	2
CD	CD	3	3
RECORD 1	Record 1	4	4
RECORD 2	Record 2	7	7
LINE 1	Line 1	6	6
LINE 2	Line 2	9	9
TRIM	Trim	-/-- GUIDE	Guide
EXIT	Exit	CLEAR EXIT	Exit
TONE	Tone	SETTINGS OPT	Options
DISPLAY	Display	DISPLAY INFO	Info
ATT	ATT	AD SUBT	Subt
+ ▲	Up/+	▲	Up
▼ −	Down/-	▼	Down
▶	Right	▶	Right

Original		Replacement	
◀	Left	◀	Left
ENTER	Enter	OK	Ok
▲ VOLUME	Vol +	+ VOL	Vol +
VOLUME ▼	Vol -	VOL −	Vol -
⏮	I <<	⏮	I <<
▶	Play	PLAY MODE ▶	Play
⏭	>>I	⏭	>>I
◀◀	<<	◀◀	<<
⏸	Pause	⏸	Pause
▶▶	>>	▶▶	>>
■	Stop	■	Stop
SCAN	Scan	SEARCH TV/R	TV/R
REPEAT	Repeat	REPEAT TEXT	Text
TOP MENU AM/A	Top Menu/M/A	SHIFT + TOP MENU MENU	Shift + Menu
RETURN FM/B	Return/FM/B	RETURN BACK	Back
MENU ◀▶	Menu/<>	TOP MENU MENU	Menu