| Original | | Replacement | |
|---|---|---|---|
| SYSTEM ON | System Power | | Power |
| POWER OFF | System Power Off | SHIFT + | Shift + Power |
| SOURCE ON/OFF | Source On/Off | NETFLIX SEARCH | Red / Netflix / Search |
| SOURCE ON/OFF | Source On/Off | APP REPEAT | Green / APP / Repeat |
| SOURCE ON/OFF | Source On/Off | Prime Video RANDOM | Blue / Prime Video / Random |
| SOURCE ON/OFF | Source On/Off CD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| SOURCE ON/OFF | Source On/Off | SHIFT + | NETFLIX SEARCH Shift + Red / Netflix / |
| SOURCE ON/OFF | Source On/Off | SHIFT + | APP REPEAT Shift + Green / APP / |
| SOURCE ON/OFF | Source On/Off | SHIFT + | YouTube REPEAT A-B Shift + Yellow / YouTube / |
| SOURCE ON/OFF | Source On/Off MD | SHIFT + | Prime Video RANDOM Shift + Blue / Prime |
| SOURCE ON/OFF | Source On/Off | SHIFT + | PC FAV MARKER Shift + Fav / Marker / PC |
| PHONO | Phono | SHIFT + | TV 1 Shift + 1 |
| CD | CD | SHIFT + | CD-STB 3 Shift + 3 |
| TUNER | Tuner | SHIFT + | TUNER 6 Shift + 6 |
| CD-R | CD-R | SHIFT + | DVD 2 Shift + 2 |
| AUX 1 | AUX1 | SHIFT + | AUX-HDD 7 Shift + 7 |
| AUX 2 | AUX2 | SHIFT + | USB 8 Shift + 8 |

| Original | | Replacement | |
|---|---|---|---|
| TAPE | Tape | SHIFT + | TAPE 5 Shift + 5 |
| MD | MD | SHIFT + | VIDEO 4 Shift + 4 |
| 1 | 1 Tuner | TV 1 | 1 |
| 2 | 2 Tuner | DVD 2 | 2 |
| 3 | 3 Tuner | CD-STB 3 | 3 |
| A.F/P | A. F/P Tuner | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 4 | 4 Tuner | VIDEO 4 | 4 |
| 5 | 5 Tuner | TAPE 5 | 5 |
| 6 | 6 Tuner | TUNER 6 | 6 |
| B.-/-- | B. -/-- Tuner | PC FAV MARKER | Fav / Marker / PC |
| 7 | 7 Tuner | AUX-HDD 7 | 7 |
| 8 | 8 Tuner | USB 8 | 8 |
| 9 | 9 Tuner | BLUETOOTH 9 | 9 |
| MODE | Mode Tuner | LIST SMART | Smart / List |
| – | - Tuner | CH PAGE – | CH- / Page- |
| 0 | 0 Tuner | HDMI-SAT 0 | 0 |
| + | + Tuner | + CH PAGE | CH+ / Page+ |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| MEMO | Memo Tuner | MEDIA DISPLAY | Display / Media | | |
| SCROLL | Scroll Tuner | RETURN BACK | Back / Return | | |
| CANCEL | Cancel Tuner | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| 1~MOD TEXT | Text / Mode 1 | GOTO TEXT | Text / Goto | | |
| ODE~2 TIME | Time/Mode 2 | TIMER SLEEP | Sleep / Timer | | |
| I<< | I<< Tuner | PRESET- I<< | I<< / Preset- | | |
| >>I | >>I Tuner | PRESET+ >>I | >>I / Preset+ | | |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | | |
| << | << Tuner | TUNE- << | << / Tune- | | |
| >> | >> Tuner | TUNE+ >> | >> / Tune+ | | |
| VOLUME ▲ | Vol + | + VOL | Vol + | | |
| VOLUME ▼ | Vol - | VOL − | Vol - | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| System Power | Power | Tape | Shift + 5 |
| System Power Off | Shift + Power | MD | Shift + 4 |
| Source On/Off | Shift + Red / Netflix / | 1 CDR | 1 |
| Source On/Off | Red / Netflix / Search | 2 CDR | 2 |
| Source On/Off | Green / APP / Repeat | 3 CDR | 3 |
| Source On/Off CD | Yellow / YouTube / Repeat | 4 CDR | 4 |
| Source On/Off | Blue / Prime Video / Random | 5 CDR | 5 |
| Source On/Off | Shift + Green / APP / | 6 CDR | 6 |
| Source On/Off | Shift + Yellow / YouTube / | 7 CDR | 7 |
| Source On/Off MD | Shift + Blue / Prime | 8 CDR | 8 |
| Source On/Off | Shift + Fav / Marker / PC | 9 CDR | 9 |
| Phono | Shift + 1 | Mode CDR | Smart / List |
| CD | Shift + 3 | - CDR | CH- / Page- |
| Tuner | Shift + 6 | 0 CDR | 0 |
| CD-R | Shift + 2 | + CDR | CH+ / Page+ |
| AUX1 | Shift + 7 | Memo CDR | Display / Media |
| AUX2 | Shift + 8 | Scroll CDR | Back / Return |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| CANCEL | Cancel CDR | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| 1~MODE TEXT | Text / Mode 1 | GOTO TEXT | Text / Goto | | |
| MODE~2 TIME | Time / Mode 2 | TIMER SLEEP | Sleep / Timer | | |
| ⏮ | I<< CDR | PRESET- ⏮ | I<< / Preset- | | |
| ▶ | Play CDR | SLOW ▶ | Play / Slow | | |
| ⏭ | >>I CDR | PRESET+ ⏭ | >>I / Preset+ | | |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | | |
| ◀◀ | << CDR | TUNE- ◀◀ | << / Tune- | | |
| ■ | Stop CDR | HOLD ■ | Stop / Hold | | |
| ▶▶ | >> CDR | TUNE+ ▶▶ | >> / Tune+ | | |
| ▲ VOLUME | Vol + | + VOL | Vol + | | |
| ⏸ | Pause CDR | STEP-FREEZE ⏸ | Pause / Step / Freeze | | |
| OPEN/ CLOSE | Open/Close | SURROUND ⏏ | Eject / Surround | | |
| VOLUME ▼ | Vol - | VOL − | Vol - | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| System Power | Power | Tape | Shift + 5 |
| System Power Off | Shift + Power | MD | Shift + 4 |
| Source On/Off | Shift + Yellow / YouTube / | 1 Tape | 1 |
| Source On/Off | Red / Netflix / Search | 2 Tape | 2 |
| Source On/Off | Green / APP / Repeat | 3 Tape | 3 |
| Source On/Off CD | Yellow / YouTube / Repeat | A. F/P Tape | Guide / EPG / -/-- |
| Source On/Off | Blue / Prime Video / Random | 4 Tape | 4 |
| Source On/Off | Shift + Red / Netflix / | 5 Tape | 5 |
| Source On/Off | Shift + Green / APP / | 6 Tape | 6 |
| Source On/Off MD | Shift + Blue / Prime | B. -/-- Tape | Fav / Marker / PC |
| Source On/Off | Shift + Fav / Marker / PC | 7 Tape | 7 |
| Phono | Shift + 1 | 8 Tape | 8 |
| CD | Shift + 3 | 9 Tape | 9 |
| Tuner | Shift + 6 | Mode Tape | Smart / List |
| CD-R | Shift + 2 | - Tape | CH- / Page- |
| AUX1 | Shift + 7 | 0 Tape | 0 |
| AUX2 | Shift + 8 | + Tape | CH+ / Page+ |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| MEMO | Memo Tape | MEDIA DISPLAY | Display / Media | | |
| CANCEL | Cancel Tape | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| 1~MODE TEXT | Text / Mode 1 | GOTO TEXT | Text / Goto | | |
| MODE~2 TIME | Time / Mode 2 | TIMER SLEEP | Sleep / Timer | | |
| ⏮ | I<< Tape | PRESET- ⏮ | I<< / Preset- | | |
| ▶ | Play Tape | SLOW ▶ | Play / Slow | | |
| ⏭ | >>I Tape | PRESET+ ⏭ | >>I / Preset+ | | |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | | |
| ◀◀ | << Tape | TUNE- ◀◀ | << / Tune- | | |
| ■ | Stop Tape | HOLD ■ | Stop / Hold | | |
| ▶▶ | >> Tape | TUNE+ ▶▶ | >> / Tune+ | | |
| VOLUME ▲ | Vol + | VOL + | Vol + | | |
| ◀▶ | <> Tape | REC MODE ● | Rec / Rec Mode | | |
| ❚❚ | Pause Tape | STEP-FREEZE ❚❚ | Pause / Step / Freeze | | |
| OPEN/ CLOSE | Open/Close | SURROUND ⏏ | Eject / Surround | | |
| VOLUME ▼ | Vol - | VOL − | Vol - | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| System Power | Power | Tape | Shift + 5 |
| System Power Off | Shift + Power | MD | Shift + 4 |
| Source On/Off | Red / Netflix / Search | 1 CD | 1 |
| Source On/Off CD | Yellow / YouTube / Repeat | 2 CD | 2 |
| Source On/Off | Green / APP / Repeat | 3 CD | 3 |
| Source On/Off | Blue / Prime Video / Random | A. F/P CD | Guide / EPG / -/-- |
| Source On/Off | Shift + Red / Netflix / | 4 CD | 4 |
| Source On/Off | Shift + Green / APP / | 5 CD | 5 |
| Source On/Off | Shift + Yellow / YouTube / | 6 CD | 6 |
| Source On/Off MD | Shift + Blue / Prime | B. -/-- CD | Fav / Marker / PC |
| Source On/Off | Shift + Fav / Marker / PC | 7 CD | 7 |
| Phono | Shift + 1 | 8 CD | 8 |
| CD | Shift + 3 | 9 CD | 9 |
| Tuner | Shift + 6 | Mode CD | Smart / List |
| CD-R | Shift + 2 | - CD | CH- / Page- |
| AUX1 | Shift + 7 | 0 CD | 0 |
| AUX2 | Shift + 8 | + CD | CH+ / Page+ |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| MEMO | Memo CD | MEDIA DISPLAY | Display / Media | | | | |
| SCROLL | Scroll CD | RETURN BACK | Back / Return | | | | |
| CANCEL | Cancel CD | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | | | |
| 1-MODE TEXT | Text / Mode 1 CD | GOTO TEXT | Text / Goto | | | | |
| MODE-2 TIME | Time / Mode 2 CD | TIMER SLEEP | Sleep / Timer | | | | |
| ⏮ | I<< CD | PRESET- ⏮ | I<< / Preset- | | | | |
| ▶ | Play CD | SLOW ▶ | Play / Slow | | | | |
| ⏭ | >>I CD | PRESET+ ⏭ | >>I / Preset+ | | | | |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | | | | |
| ◀◀ | << CD | TUNE- ◀◀ | << / Tune- | | | | |
| ■ | Stop CD | HOLD ■ | Stop / Hold | | | | |
| ▶▶ | >> CD | TUNE+ ▶▶ | >> / Tune+ | | | | |
| VOLUME ▲ | Vol + | VOL + | Vol + | | | | |
| ❚❚ | Pause CD | STEP-FREEZE ❚❚ | Pause / Step / Freeze | | | | |
| OPEN/ CLOSE | Open/Close CD | SURROUND ⏏ | Eject / Surround | | | | |
| VOLUME ▼ | Vol - | VOL − | Vol - | | | | |