Original	Replacement	Original	Replacement
AMP Power	Power	Vol -	Vol -
Power	Shift + Power	Mute	Mute
CD	Yellow	Time/Top Menu	Menu
Tuner	Green	Mode	Back
Network	Media	Prog/Favorites	Pre Ch
Phono	Smart	Setup	Options
AUX	Red	Up	Up
Recorder	Blue	Down	Down
I<<	I<<	Right	Right
>>I	>>I	Left	Left
Stop	Stop	Enter	Ok
Play	Play	1	1
Pause	Pause	2	2
Input	AV	3	3
Info	Info	4	4
Source Direct	3D	5	5
Vol +	Vol +	6	6

Original		Replacement		Original		Replacement	
PQRS 7	7	7	7				
TUV 8	8	8	8				
WXYZ 9	9	9	9				
0	0	0	0				
a/A +10	+10	-/-- GUIDE	Guide				
CLEAR	Clear	CLEAR EXIT	Exit				
DIMMER	Dimmer	PICTURE FORMAT	Format				
RANDOM	Random	AD SUBT	Subt				
REPEAT	Repeat	REPEAT TEXT	Text				
SEARCH	Search	SEARCH TV/R	TV/R				

Original		Replacement	
AMP POWER	AMP Power		Power
POWER	Power	SHIFT +	Shift + Power
CD	CD	C	Yellow
TUNER	Tuner	B	Green
NETWORK	Network	APP MEDIA	Media
PHONO	Phono	HOME SMART	Smart
AUX	AUX	A	Red
RECORDER	Recorder	D	Blue
I<<	I<<	I<<	I<<
SOUND MODE	Sound Mode	SOUND DUAL	Dual
>>I	>>I	>>I	>>I
Stop	Stop		Stop
Play	Play	PLAY MODE	Play
Pause	Pause		Pause
INPUT	Input	TIMER AV	AV
INFO	Info	DISPLAY INFO	Info
SOURCE DIRECT	Source Direct	ECO 3D	3D

Original		Replacement	
VOLUME	Vol +	VOL +	Vol +
VOLUME	Vol -	VOL -	Vol -
MUTE	Mute	MUTE	Mute
TOP MENU TIME	Time/Top Menu	TOP MENU MENU	Menu
MODE	Mode	RETURN BACK	Back
FAVORITES PROG	Prog/Favorites	FAV PRE-CH	Pre Ch
SETUP	Setup	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5

Original		Replacement		Original		Replacement	
MNO 6	6	6	6				
PQRS 7	7	7	7				
TUV 8	8	8	8				
WXYZ 9	9	9	9				
0	0	0	0				
a/A +10	+10	-/-- GUIDE	Guide				
CLEAR	Clear	CLEAR EXIT	Exit				
DIMMER	Dimmer	PICTURE FORMAT	Format				
RANDOM	Random	AD SUBT	Subt				
REPEAT	Repeat	REPEAT TEXT	Text				