Original	Replacement
Power Receiver	Power
1	1
VCR / DVR	Shift + 4
2	2
CBL / SAT	Shift + 0
3	3
4	4
AUX	Shift + 7
5	5
Multi CH	Shift + 1
6	6
DVD	Shift + 2
7	7
TAPE	Shift + 5
8	8
TUNER	Shift + 6
9	9

Original	Replacement
CD	Shift + 3
D. TUN	Smart / List
Dimmer	Shift + Mute / Dimmer
0	0
Sleep	Sleep / Timer
CH+	CH+ / Page+
Vol +	Vol +
CH-	CH- / Page-
Vol -	Vol -
SP A/B	Info / Angle
Up	Up
Muting	Mute / Dimmer
Left	Left
Enter	OK
Right	Right
Setup	Setup / OPT /
Down	Down

Original	Replacement	Original	Replacement
RETURN Return	RETURN BACK Back / Return	L NIGHT DVD L. Night	HOME MENU Menu / Home
Pause / Play Rev	STEP-FREEZE Pause / Step / Freeze	CINE FLTR HDD Cine FLTR	TOP MENU D.MENU D. Menu / Top
Play	SLOW Play / Slow		
Stop	HOLD Stop / Hold		
<<	TUNE- << / Tune-		
>>	TUNE+ >> / Tune+		
I<<	PRESET- I<< / Preset-		
>>I	PRESET+ >>I / Preset+		
STEREO Stereo	LANG I/II AUDIO Audio / Lang I/II		
SURROUND Surround	SURROUND Eject / Surround		
< Listening Mode	SHIFT + PRESET- I<< / Preset- Shift +		
Listening Mode >	SHIFT + PRESET+ >>I / Preset+ Shift +		
AUDIO TEST TONE Test Tone	NETFLIX SEARCH Red / Netflix / Search		
SUBTITLE CH SEL CH Sel	APP REPEAT Green / APP / Repeat		
RANDOM LEVEL- Level -	YouTube REPEAT A-B Yellow / YouTube / Repeat		
REPEAT LEVEL+ Level +	Prime Video RANDOM Blue / Prime Video / Random		
DISPLAY Display	MEDIA DISPLAY Display / Media		

Original		Replacement	
STANDBY/ON	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10/10/-/--		-/-- GUIDE EPG	Guide / EPG / -/--
0/11		HDMI-SAT 0	0
CLR/12/Sleep		TIMER SLEEP	Sleep / Timer
CLR/12/Sleep		CLEAR EXIT CANCEL	Exit / Cancel / Clear
Guide/Top		TOP MENU D.MENU	D. Menu / Top
Up			Up
Previous Menu/Muting		HOME MENU	Menu / Home

Original		Replacement	
Left/Playlist/Ca			Left
ENTER	Enter	OK	OK
Right/Playlist/C			Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
Down			Down
RETURN	Return	RETURN BACK	Back / Return
Pause		STEP-FREEZE	Pause / Step / Freeze
Play		SLOW	Play / Slow
Stop		HOLD	Stop / Hold
<<		TUNE-	<< / Tune-
>>		TUNE+	>> / Tune+
I<<		PRESET-	I<< / Preset-
>>I		PRESET+	>>I / Preset+
STEREO	Stereo	TITLE SOUND	Sound / Title
SURROUND	Surround		Eject / Surround
< Listening Mode		SHIFT + PRESET-	Shift + I<< / Preset-
Listening Mode >		SHIFT + PRESET+	Shift + >>I / Preset+

Original		Replacement		Original	Replacement
AUDIO / TEST TONE	Audio	LANG I/II / AUDIO	Audio / Lang I/II		
SUBTITLE / CH SEL	Subtitle	EQ / SUBTITLE	Subtitle / EQ		
RANDOM / LEVEL-	Level - / Random	Prime Video / RANDOM	Blue / Prime Video / Random		
REPEAT / LEVEL+	Level + / Repeat	APP / REPEAT	Green / APP / Repeat		
DISPLAY	Display	MEDIA / DISPLAY	Display / Media		
PLAY MODE / VCR	Play Mode VCR	SHIFT + VIDEO 4	Shift + 4		
L NIGHT / DVD	Play Mode DVD	SHIFT + DVD 2	Shift + 2		
CINE FILTR / HDD	Play Mode HDD	SHIFT + AUX - HDD 7	Shift + 7		

Original		Replacement	
STANDBY/ON	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10/10/-/--		GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
CLR/12/Sleep		TIMER SLEEP	Sleep / Timer
CLR/12/Sleep		CLEAR EXIT CANCEL	Exit / Cancel / Clear
Disc/Album		CH PAGE +	CH+ / Page+
Vol +		VOL +	Vol +
CH DISC ALBUM −	Disc/Album CH-	CH PAGE −	CH- / Page-

Original		Replacement	
VOL	Vol -	VOL −	Vol -
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
RANDOM LEVEL-	Level -/Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Level +/Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
STANDBY/ON	Standby / On		Power
VCR/DVR	VCR/DVR	VIDEO 4	4
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
AUX	AUX	AUX - HDD 7	7
MULTI CH	Multi CH	TV 1	1
DVD	DVD	DVD 2	2
TAPE	Tape	TAPE 5	5
TUNER	Tuner	TUNER 6	6
CD	CD	CD - STB 3	3
D.TUN	D.Tun	LIST SMART	Smart / List
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
CLR SLEEP	CLR / Sleep	TIMER SLEEP	Sleep / Timer
CLR SLEEP	CLR / Sleep	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH DISC ALBUM	CH Disc	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
CH DISC ALBUM	CH Disc Album	CH PAGE −	CH- / Page-
VOL	Vol -	VOL −	Vol -

Original		Replacement	
	Up		Up
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
PLAYLIST/CAT	Left/Playlist/Ca		Left
ENTER	Enter	OK	OK
PLAYLIST/CAT	Right/Playlist/C		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
	Rev. Play	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround		Eject / Surround
	< Listening Mode	PRESET-	I<< / Preset-
	Listening Mode >	PRESET+	>>I / Preset+

Original		Replacement		Original	Replacement
AUDIO TEST TONE	Test Tone	NETFLIX SEARCH	Red / Netflix / Search		
SUBTITLE CH SEL	CH Sel	APP REPEAT	Green / APP / Repeat		
RANDOM LEVEL-	Level -	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
REPEAT LEVEL+	Level +	Prime Video RANDOM	Blue / Prime Video / Random		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
L NIGHT DVD	L. Night / Play Mode DVD	HOME MENU	Menu / Home		
CINE FLTR HDD	Cine FLTR / Play Mode HDD	TOP MENU D.MENU	D. Menu / Top		