Original	Replacement
RCVR Sleep	Sleep / Timer
RCVR On	Power
RCVR Standby	Shift + Power
RCVR Return	Back / Return
RCVR Setup	Setup / OPT /
RCVR Disc+	CH+ / Page+
RCVR Up	Up
RCVR Vol +	Vol +
RCVR Disc-	CH- / Page-
RCVR Left	Left
RCVR Enter	OK
RCVR Right	Right
RCVR Vol -	Vol -
RCVR Down	Down
RCVR Audio	Audio / Lang I/II
RCVR CH Sel / Top Menu	D. Menu / Top
RCVR Test / Menu	Menu / Home

Original	Replacement
RCVR Muting	Mute / Dimmer
RCVR Level	Shift + Down
RCVR Level Up	Shift + Up
RCVR I <<	I << / Preset-
RCVR Play	Play / Slow
RCVR >>I	>>I / Preset+
RCVR <<	<< / Tune-
RCVR Stop	Stop / Hold
RCVR >>	>> / Tune+
RCVR Rec /	Blue / Prime Video / Random
RCVR Pause / Play Rev.	Pause / Step / Freeze
Open / Close	Eject / Surround
RCVR Input Sel.	2
RCVR Input Sel.	3
RCVR Input Sel.	4
RCVR Input Sel.	1
RCVR Input Sel.	5

TAP

Original		Replacement	
TUN	RCVR Input Sel.	TUNER 6	6
V3	RCVR Input Sel.	AUX - HDD 7	7
V4	RCVR Input Sel.	USB 8	8
V5	RCVR Input Sel.	BLUETOOTH 9	9
PH	RCVR Input Sel.	HDMI - SAT 0	0
1 STEREO	RCVR Stereo	SHIFT + TV 1	Shift + 1
2 DIRECT	RCVR Direct	SHIFT + DVD 2	Shift + 2
3 DSP ►	RCVR DSP ►	SHIFT + CD - STB 3	Shift + 3
4 SURR	RCVR SURR	SHIFT + VIDEO 4	Shift + 4
4 SURR	RCVR SURR	SHIFT + SURROUND ⏏	Shift + Eject / Surround
5 THX	RCVR THX	SHIFT + TAPE 5	Shift + 5
6 DSP ◄	RCVR ◄ DSP	SHIFT + TUNER 6	Shift + 6
7 SP A	RCVR SP A	SHIFT + AUX - HDD 7	Shift + 7
8 SP B	RCVR SP B	SHIFT + USB 8	Shift + 8
9 Re-EQ	RCVR Re-EQ	EQ SUBTITLE	Subtitle / EQ
9 Re-EQ	RCVR Re-EQ	SHIFT + BLUETOOTH 9	Shift + 9
+10 DISPLAY	RCVR Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
0 DIMMER	RCVR Dimmer	SHIFT + HDMI - SAT 0	Shift + 0
0 DIMMER	RCVR Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SEARCH ZONE 2 ENTER	RCVR Zone 2	LIST SMART	Smart / List

Original		Replacement	
	ON		Power
	STDBY		Shift + Power
	Return		Back / Return
	Setup		Setup / OPT /
	Disc+		CH+ / Page+
	Up		Up
	Vol +		Vol +
	Disc-		CH- / Page-
	Left		Left
	Enter		OK
	Right		Right
	Vol -		Vol -
	Down		Down
	Top Menu		D. Menu / Top
	Menu		Menu / Home
	Muting		Mute / Dimmer
	Angle		Info / Angle

Original		Replacement	
	Subtitle		Subtitle / EQ
	I<<		I<< / Preset-
	Play		Play / Slow
	>>I		>>I / Preset+
	<<		<< / Tune-
	Stop		Stop / Hold
	>>		>> / Tune+
	Random		Blue / Prime Video / Random
	Pause		Pause / Step / Freeze
	Open / Close		Eject / Surround
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7

Original		Replacement		Original	Replacement
8 SP B	8	USB 8	8		
9 Re-EQ	9	BLUETOOTH 9	9		
+10 DISPLAY	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
0 DIMMER	0	HDMI - SAT 0	0		
SEARCH ZONE 2 ENTER	Search	NETFLIX SEARCH	Red / Netflix / Search		

Original		Replacement	
ON	ON	Power	
STDBY	STDBY	SHIFT + Power	Shift + Power
Disc+	CH DISC	CH+ / Page+	CH PAGE
Vol +	VOL	Vol +	VOL
Vol -	VOL	Vol -	VOL
Muting	MUTING M	Mute / Dimmer	DIMMER MUTE
I<<		I<< / Preset-	PRESET-
Play		Play / Slow	SLOW
>>I		>>I / Preset+	PRESET+
<<		<< / Tune-	TUNE-
Stop		Stop / Hold	HOLD
>>		>> / Tune+	TUNE+
Random	RANDOM R	Blue / Prime Video / Random	Prime Video RANDOM
Pause		Pause / Step / Freeze	STEP-FREEZE
Open / Close	OPEN/CLOSE	Eject / Surround	SURROUND
1	1 STEREO	1	TV 1
2	2 DIRECT	2	DVD 2

Original		Replacement	
3	3 DSP	3	CD-STB 3
4	4 SURR	4	VIDEO 4
5	5 THX	5	TAPE 5
6	6 DSP	6	TUNER 6
7	7 SP A	7	AUX-HDD 7
8	8 SP B	8	USB 8
9	9 Re-EQ	9	BLUETOOTH 9
+10	+10 DISPLAY	-/--	GUIDE EPG
0	0 DIMMER	0	HDMI-SAT 0

Original		Replacement		Original		Replacement	
ON	ON	Power		1 STEREO	1	TV 1	1
STDBY	STDBY	SHIFT +	Shift + Power	2 DIRECT	2	DVD 2	2
VOL	Vol +	VOL +	Vol +	3 DSP	3	CD-STB 3	3
ENTER	Enter	OK	OK	4 SURR	4	VIDEO 4	4
ENTER	Enter	PC FAV MARKER	Fav / Marker / PC	5 THX	5	TAPE 5	5
VOL	Vol -	VOL −	Vol -	6 DSP	6	TUNER 6	6
MUTING M	Muting	DIMMER MUTE	Mute / Dimmer	7 SP A	7	AUX-HDD 7	7
I<<	I<<	PRESET- I<<	I<< / Preset-	8 SP B	8	USB 8	8
Play	Play	SLOW	Play / Slow	9 Re-EQ	9	BLUETOOTH 9	9
>>I	>>I	PRESET+ >>I	>>I / Preset+	+10 DISPLAY	+10	-/-- GUIDE EPG	Guide / EPG / -/--
<<	<<	TUNE- <<	<< / Tune-	0 DIMMER	0	HDMI-SAT 0	0
Stop	Stop	HOLD	Stop / Hold				
>>	>>	TUNE+ >>	>> / Tune+				
RANDOM R	Rec / Random	Prime Video RANDOM	Blue / Prime Video / Random				
RANDOM R	Rec / Random	REC MODE	Rec / Rec Mode				
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze				
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround				