Mandis shop

076R0HM01B

Original	Replacement
Power	Power
TV/VCR	TV/Radio /
DVD	SHIFT + DVD 2 — Shift + 2
CH/Page+	CH+ / Page+
1	1
2	2
3	3
CH/Page-	CH- / Page-
4	4
5	5
6	6
Vol +	Vol +
7	7
8	8
9	9
Vol -	Vol -
0/AV	0

Original	Replacement
0/AV	RDS AV INPUT — AV / Input / RDS
Display	ANGLE INFO — Info / Angle
Setup / Menu	OPT-TOOLS SETUP — Setup / OPT /
Setup / Menu	HOME MENU — Menu / Home
Up / Green	Up
Up / Green	APP REPEAT — Green / APP / Repeat
Mute	DIMMER MUTE — Mute / Dimmer
Left / Red	Left
Left / Red	NETFLIX SEARCH — Red / Netflix / Search
Enter/Text/Mix/T	OK — OK
Enter/Text/Mix/T	GOTO TEXT — Text / Goto
Right / Blue	Right
Right / Blue	Prime Video RANDOM — Blue / Prime Video / Random
DVD Menu	TOP MENU D.MENU — D.Menu / Top
Down / Yellow	Down
Down / Yellow	YouTube REPEAT A-B — Yellow / YouTube / Repeat
F/T/B CANCEL — Cancel / F/T/B	CLEAR EXIT CANCEL — Exit / Cancel / Clear

Original	Replacement
REW <<	TUNE- << / Tune-
PLAY Play	SLOW Play / Slow
F.FWD >>	TUNE+ >> / Tune+
TRK/SKIP TRK/Skip-/I<<	PRESET- I<< / Preset-
TRK/SKIP TRK/Skip-/>>I	PRESET+ >>I / Preset+
STOP Stop	HOLD Stop / Hold
PAUSE/STILL Pause/Still	STEP-FREEZE Pause / Step / Freeze
REC/OTR Rec/Otr	REC MODE Rec / Rec Mode
TIMER REC Timer Rec	SHIFT + TIMER SLEEP Shift + Sleep / Timer
SUB PAGE INDEX Index/Sub page	LIST SMART Smart / List
SLOW Slow	SHIFT + STEP-FREEZE Shift + Pause / Step /
REPEAT A-B PROGRAM Repeat	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /
REPEAT A-B PROGRAM Repeat	SHIFT + PROGRAM TV/RADIO Shift + TV/Radio / Program
JUMP/HOLD SP/LP Jump/Hold/SP/L	FORMAT PICTURE Picture / Format
ANGLE COUNTER RESET Angle/Counter	SHIFT + ANGLE INFO Shift + Info / Angle
SUBTITLE ZERO RETURN Subtitle/Zero return	EQ SUBTITLE Subtitle / EQ
ZOOM REVEAL Zoom/Reveal	SIZE ZOOM Zoom / Size

Original	Replacement
TITLE ATR Title/ATR	TITLE SOUND Sound / Title
RETURN Return	RETURN BACK Back / Return
PLAY MODE QUICK VIEW Play Mode/Quick View	MEDIA DISPLAY Display / Media
SLEEP Sleep	TIMER SLEEP Sleep / Timer
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II
EJECT Eject	SHIFT + SURROUND Shift + Eject / Surround
OPEN/CLOSE Open/Close	SURROUND Eject / Surround