Original		Replacement	
	Power		Power
	Select Drive		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Input Select		Media
	CH+/ Tracking/V-Lock		Ch +
	CH-/ Tracking/V-Lock/		Ch -
	ShowView		Pre Ch
	Pause		Pause

Original		Replacement	
	Play		Play
	Stop		Stop
	>>		>>
	<<		<<
	>>I		>>I
	I <<		I <<
	i/Status		Info
	Return		Back
	Exit		Exit
	Function Menu		Menu
	Prog/Check		TV/R
	Option		Options
	Delete/Reset		Shift + Exit
	Guide		Guide
	Direct Navigator		D. Menu
	OK		Ok
	Up		Up

Original		Replacement	
Down	Down	Down	Down
Right	Right	Right	Right
Left	Left	Left	Left
Red	Red	A	Red
CHAPTER	Green/Chapter	B	Green
MANUAL S -10s	Yellow/Manual Skip -10S	C	Yellow
SKIP +60s	Blue//Manual Skip +60S	D	Blue
REC	Rec	REC MODE	Rec
DIRECT TV REC	Direct Tv Rec	SHIFT + SEARCH TV/R	Shift + TV/R
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec
EXT LINK	Ext Link	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info
STTL	[≡◆] / STTL	AD SUBT	Subt
TIME SLIP JET REW	Time Slip/ <<Jet	PROG SLEEP	Sleep
TIME SLIP JET REW	Time Slip/ <<Jet	SHIFT + <<	Shift + <<
TV	Tv Power	SHIFT +	Shift + Power

Original		Replacement	
AV	AV Tv	TIMER AV	AV
+ VOL	Vol + Tv	+ VOL	Vol +
VOL −	Vol - Tv	VOL −	Vol -
CH	CH+ Tv	SHIFT + + CH	Shift + Ch +
CH	CH- Tv	SHIFT + CH −	Shift + Ch -