| Original | | Replacement | |
|---|---|---|---|
| | Power TV | | Power |
| | 1 TV | 1 | 1 |
| | 2 TV | 2 | 2 |
| | 3 TV | 3 | 3 |
| | 4 TV | 4 | 4 |
| | 5 TV | 5 | 5 |
| | 6 TV | 6 | 6 |
| | 7 TV | 7 | 7 |
| | 8 TV | 8 | 8 |
| | 9 TV | 9 | 9 |
| | 0/-- TV | 0 | 0 |
| | AV TV | TIMER AV | AV |
| | Vol + | + VOL | Vol + |
| | Vol - | VOL − | Vol - |
| | Mute | MUTE | Mute |
| | Return TV | RETURN BACK | Back |
| | PR+ TV | + CH | Ch + |

| Original | | Replacement | |
|---|---|---|---|
| | PR- TV | CH − | Ch - |
| | Play TV | PLAY MODE | Play |
| | << TV | << | << |
| | >> TV | >> | >> |
| | Record TV | REC MODE | Rec |
| | Stop TV | | Stop |
| | Pause TV | | Pause |
| | Exit TV | CLEAR EXIT | Exit |
| | Menu TV | TOP MENU MENU | Menu |
| | Violet/Text TV | REPEAT TEXT | Text |
| | Red/Presets TV | A | Red |
| | Green/List TV | B | Green |
| | Yellow/Info TV | C | Yellow |
| | Blue/Guide TV | D | Blue |
| | Up TV | | Up |
| | Down TV | | Down |
| | Right/Zoom+ | | Right |

| Original | Replacement |
|---|---|
| Left / Zoom- TV | Left |
| OK TV | Ok |
| TV | TV/R |
| Demo TV | Pre Ch |
| VCR | Smart |
| SAT | Media |
| DVD | Options |
| AUX | Format |
| AMP | 3D |
| Power AUX | Shift + Power |
| Red/Presets | Shift + Red |
| Green/List AUX | Shift + Green |
| Yellow/Info AU | Shift + Yellow |
| Blue/Guide AUX | Shift + Blue |
| Up AUX | Shift + Up |
| OK AUX | Shift + Ok |
| Down AUX | Shift + Down |

| Original | Replacement |
|---|---|
| Right / Zoom+ | Shift + Right |
| Left / Zoom- AUX | Shift + Left |
| Exit AUX | Shift + Exit |
| Menu AUX | Shift + Menu |
| Violet/Text AU | Shift + Text |
| Return AUX | Shift + Back |
| PR+ AUX | Shift + Ch + |
| PR- AUX | Shift + Ch - |
| 1 AUX | Shift + 1 |
| 2 AUX | Shift + 2 |
| 3 AUX | Shift + 3 |
| 4 AUX | Shift + 4 |
| 5 AUX | Shift + 5 |
| 6 AUX | Shift + 6 |
| 7 AUX | Shift + 7 |
| 8 AUX | Shift + 8 |
| 9 AUX | Shift + 9 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 0/-- 0 AUX | SHIFT + 0 Shift + 0 | | |
| PLAY Play AUX | SHIFT + PLAY MODE Shift + Play | | |
| REVERSE << AUX | SHIFT + << Shift + << | | |
| FORWARD >> AUX | SHIFT + >> Shift + >> | | |
| STOP Stop AUX | SHIFT + ■ Shift + Stop | | |
| RECORD Record AUX | SHIFT + REC MODE Shift + Rec | | |
| PAUSE Pause AUX | SHIFT + II Shift + Pause | | |
| AV AV AUX | SHIFT + TIMER AV Shift + AV | | |
| DEMO Demo AUX | SHIFT + FAV PRE-CH Shift + Pre Ch | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power DVD | | Power |
| PRESETS | Red/Presets | A | Red |
| LIST | Green/List DVD | B | Green |
| INFO | Yellow/Info DVD | C | Yellow |
| GUIDE | Blue/Guide DVD | D | Blue |
| TEXT | Violet/Text DVD | REPEAT TEXT | Text |
| | Up DVD | | Up |
| | Down DVD | | Down |
| ZOOM | Right/Zoom+ | | Right |
| ZOOM | Left/Zoom- DVD | | Left |
| OK | OK DVD | OK | Ok |
| EXIT | Exit DVD | CLEAR EXIT | Exit |
| MENU | Menu DVD | TOP MENU MENU | Menu |
| | Vol + | + VOL | Vol + |
| | Vol - | VOL − | Vol - |
| | Mute | MUTE | Mute |
| RETURN | Return DVD | RETURN BACK | Back |

| Original | | Replacement | |
|---|---|---|---|
| PR + | PR+ DVD | + CH | Ch + |
| PR - | PR- DVD | CH − | Ch - |
| 1 | 1 DVD | 1 | 1 |
| 2 | 2 DVD | 2 | 2 |
| 3 | 3 DVD | 3 | 3 |
| 4 | 4 DVD | 4 | 4 |
| 5 | 5 DVD | 5 | 5 |
| 6 | 6 DVD | 6 | 6 |
| 7 | 7 DVD | 7 | 7 |
| 8 | 8 DVD | 8 | 8 |
| 9 | 9 DVD | 9 | 9 |
| 0/-- | 0 DVD | 0 | 0 |
| AV | AV DVD | TIMER AV | AV |
| DEMO | Demo DVD | FAV PRE-CH | Pre Ch |
| PLAY | Play DVD | PLAY MODE | Play |
| REVERSE | << DVD | « | << |
| FORWARD | >> DVD | » | >> |

| Original | Replacement |
|---|---|
| Record DVD | REC MODE Rec |
| Stop DVD | Stop |
| Pause | Pause |
| TV | SEARCH TV/R TV/R |
| VCR | HOME SMART Smart |
| SAT | APP MEDIA Media |
| DVD | SETTINGS OPT Options |
| AUX | PICTURE FORMAT Format |
| AMP | ECO 3D 3D |
| Power VCR | SHIFT + Power Shift + Power |
| Red/Presets | SHIFT + A Shift + Red |
| Green/List VCR | SHIFT + B Shift + Green |
| Yellow/Info VC | SHIFT + C Shift + Yellow |
| Blue/Guide VCR | SHIFT + D Shift + Blue |
| Violet/Text VC | SHIFT + REPEAT TEXT Shift + Text |
| Exit VCR | SHIFT + CLEAR EXIT Shift + Exit |
| Menu VCR | SHIFT + TOP MENU MENU Shift + Menu |

| Original | Replacement |
|---|---|
| Up VCR | SHIFT + ▲ Shift + Up |
| Down VCR | SHIFT + ▼ Shift + Down |
| Right/Zoom+ | SHIFT + ▶ Shift + Right |
| Left/Zoom- VCR | SHIFT + ◀ Shift + Left |
| OK VCR | SHIFT + OK Shift + Ok |
| Return VCR | SHIFT + RETURN BACK Shift + Back |
| PR+ VCR | SHIFT + + CH Shift + Ch + |
| PR- VCR | SHIFT + CH − Shift + Ch - |
| 1 VCR | SHIFT + 1 Shift + 1 |
| 2 VCR | SHIFT + 2 Shift + 2 |
| 3 VCR | SHIFT + 3 Shift + 3 |
| 4 VCR | SHIFT + 4 Shift + 4 |
| 5 VCR | SHIFT + 5 Shift + 5 |
| 6 VCR | SHIFT + 6 Shift + 6 |
| 7 VCR | SHIFT + 7 Shift + 7 |
| 8 VCR | SHIFT + 8 Shift + 8 |
| 9 VCR | SHIFT + 9 Shift + 9 |

| Original | | Replacement | Original | Replacement |
|---|---|---|---|---|
| 0/-- | 0 VCR | SHIFT + 0 Shift + 0 | | |
| REVERSE | << VCR | SHIFT + << Shift + << | | |
| FORWARD | >> VCR | SHIFT + >> Shift + >> | | |
| PLAY | Play VCR | SHIFT + PLAY MODE Shift + Play | | |
| AV | AV VCR | SHIFT + TIMER AV Shift + AV | | |
| STOP | Stop VCR | SHIFT + ■ Shift + Stop | | |
| RECORD | Record VCR | SHIFT + REC MODE Shift + Rec | | |
| PAUSE | Pause VCR | SHIFT + II Shift + Pause | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| TV | TV | SEARCH TV/R | TV/R |
| VCR | VCR | HOME SMART | Smart |
| SAT | SAT | APP MEDIA | Media |
| DVD | DVD | SETTINGS OPT | Options |
| AUX | AUX | PICTURE FORMAT | Format |
| AMP | AMP | ECO 3D | 3D |
| PRESETS | Red/Presets | A | Red |
| LIST | Green/List | B | Green |
| INFO | Yellow/Info | C | Yellow |
| GUIDE | Blue/Guide | D | Blue |
| TEXT | Violet/Text | REPEAT TEXT | Text |
| | Up | | Up |
| | Down | | Down |
| ZOOM + | Right/Zoom+ | | Right |
| ZOOM - | Left/Zoom- | | Left |
| OK | OK | OK | Ok |

| Original | | Replacement | |
|---|---|---|---|
| EXIT | Exit | CLEAR EXIT | Exit |
| MENU | Menu | TOP MENU MENU | Menu |
| + | Vol + | + VOL | Vol + |
| - | Vol - | VOL – | Vol - |
| | Mute | MUTE | Mute |
| RETURN | Return | RETURN BACK | Back |
| + PR | PR+ | + CH | Ch + |
| PR - | PR- | CH – | Ch - |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 0/-- | 0 | 0 | 0 | | |
| AV | AV | TIMER AV | AV | | |
| DEMO | Demo | FAV PRE-CH | Pre Ch | | |
| REVERSE | << | << | << | | |
| PLAY | Play | PLAY MODE | Play | | |
| FORWARD | >> | >> | >> | | |
| RECORD | Record | REC MODE | Rec | | |
| STOP | Stop | | Stop | | |
| PAUSE | Pause | | Pause | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| TV | TV | SEARCH TV/R | TV/R |
| VCR | VCR | HOME SMART | Smart |
| SAT | SAT | APP MEDIA | Media |
| DVD | DVD | SETTINGS OPT | Options |
| AUX | AUX | PICTURE FORMAT | Format |
| AMP | AMP | ECO 3D | 3D |
| PRESETS | Red/Presets | A | Red |
| INFO | Yellow/Info | C | Yellow |
| GUIDE | Blue/Guide | D | Blue |
| TEXT | Violet/Text | REPEAT TEXT | Text |
| | Up | | Up |
| | Down | | Down |
| ZOOM + | Right/Zoom+ | | Right |
| ZOOM - | Left/Zoom- | | Left |
| OK | OK | OK | Ok |
| EXIT | Exit | CLEAR EXIT | Exit |

| Original | | Replacement | |
|---|---|---|---|
| MENU | Menu | TOP MENU MENU | Menu |
| + | Vol + | + VOL | Vol + |
| - | Vol - | VOL – | Vol - |
| | Mute | MUTE | Mute |
| RETURN | Return | RETURN BACK | Back |
| PR + | PR+ | + CH | Ch + |
| PR - | PR- | CH – | Ch - |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0/-- | 0 | 0 | 0 |

| Original | | Replacement | |
|---|---|---|---|
| AV | AV | TIMER AV | AV |
| REVERSE | << | << | << |
| PLAY | Pl ay | PLAY MODE | Pl ay |
| FORWARD | >> | >> | >> |
| RECORD | Recor d | REC MODE | Rec |
| STOP | St op | | St op |
| PAUSE | Pause | | Pause |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |