Mandis shop

Philips RC1913300501H

Original		Replacement	
POWER	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
RETURN RESUME	Resume/Return	RETURN BACK	Back
DISPLAY	Display	DISPLAY INFO	Info
DISC MENU	Menu Disc	E-MANUAL D.MENU	D. Menu
SYSTEM MENU	Menu System	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down

Original		Replacement	
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok
◀◀	<<	<<	<<
▶▶	>>	>>	>>
STOP ■	Stop	■	Stop
PLAY ▶	Play	PLAY MODE ▶	Play
PAUSE II	Pause	II	Pause
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	SETTINGS OPT	Options
ZOOM	Zoom	ZOOM ⏏	Eject
AUDIO	Audio	SOUND DUAL	Dual
REPEAT	Repeat	REPEAT TEXT	Text
REPEAT A-B	A-B Repeat	SEARCH TV/R	TV/R
SHUFFLE	Shuffle	APP MEDIA	Media
SCAN	Scan	TIMER AV	AV

https://remotecontrols.at/en/Philips/10952-785-replacement-remote-control-for-Philips-RC1913300501H-13928971.html