Original		Replacement	
	Power		Power
OPEN/CLOSE	Open / Close	ZOOM	Eject
CD	CD	B	Green
TUNER	TUNER	A	Red
MP3 LINK USB	USB / MP3 LINK	C	Yellow
TAPE	TAPE	D	Blue
	Up		Up
	Left / I<<		Left
	Left / I<<		I<<
	Play/Pause		Pause
	Play/Pause	PLAY MODE	Play
	Play/Pause	OK	Ok
	Right / >>I		Right
	Right / >>I		>>I
	Down		Down
RDS DISPLAY	Display / RDS	DISPLAY INFO	Info
	Mute	MUTE	Mute

Original		Replacement	
	Stop		Stop
VOL −	Vol -	VOL −	Vol -
VOL +	Vol +	+ VOL	Vol +
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PROG	Prog	PROG SLEEP	Sleep
SLEEP/ TIMER	Sleep / Timer	TIMER AV	AV
DSC	DSC	HOME SMART	Smart
DBB	DBB	APP MEDIA	Media

Original		Replacement	
	Power		Power
OPEN/CLOSE	Open / Close	ZOOM	Eject
CD	CD	B	Green
TUNER	TUNER	A	Red
MP3 LINK USB	USB / MP3 LINK	C	Yellow
TAPE	TAPE	D	Blue
	Up		Up
	Left / I<<	I<<	I<<
	Left / I<<		Left
	Play / Pause	PLAY MODE	Play
	Play / Pause	II	Pause
	Play / Pause	OK	Ok
	Right / >>I		Right
	Right / >>I	>>I	>>I
	Down		Down
RDS DISPLAY	Display / RDS	DISPLAY INFO	Info
	Mute	MUTE	Mute

Original		Replacement	
	Stop		Stop
VOL –	Vol -	VOL –	Vol -
VOL +	Vol +	+ VOL	Vol +
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PROG	Prog	PROG SLEEP	Sleep
REPEAT/ SHUFFLE	Repeat / Shuffle	REPEAT TEXT	Text
SLEEP/ TIMER	Sleep / Timer	TIMER AV	AV
DSC	DSC	HOME SMART	Smart

Original	Replacement	Original	Replacement
DBB	Media		

Original		Replacement	
	Power		Power
	Open/Close		Eject
	CD		Green
	TUNER		Red
	USB / MP3 LINK		Yellow
	TAPE		Blue
	Up		Up
	Left		Left
	I <<		I <<
	Ok		Ok
	Pause		Pause
	Play		Play
	>>I		>>I
	Right		Right
	Down		Down
	RDS/Display		Info
	Mute		Mute

Original		Replacement	
	Stop		Stop
	Vol -		Vol -
	Vol +		Vol +
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Prog		Options
	Repeat/Shuffle		Text
	Sleep/Timer		Sleep
	DSC		Smart

Original	Replacement	Original	Replacement
DBB	Media		

Original		Replacement	
	Power		Power
CD	CD	A	Red
TUNER	TUNER	B	Green
MP3 LINK USB	USB / MP3 LINK	C	Yellow
TAPE	TAPE	D	Blue
	I<		I<<
	<<		<<
	Play/Pause	PLAY MODE	Play
	Play/Pause		Pause
	>I		>>I
	>>		>>
	Mute	MUTE	Mute
	Stop		Stop
VOL -	Vol -	VOL –	Vol -
VOL +	Vol +	+ VOL	Vol +
REPEAT/ SHUFFLE	Repeat	REPEAT TEXT	Text
REPEAT/ SHUFFLE	Shuffle	SEARCH TV/R	TV/R

Original		Replacement	
SLEEP/ TIMER	Sleep	PROG SLEEP	Sleep
DSC	DSC	APP MEDIA	Media
DBB	DBB	HOME SMART	Smart