Original	Replacement	Original	Replacement
Power	Power	>>I	>>I / Preset+
Power USB/Audio	Smart / List	>>I CD/FM	Right
Open/Close	Eject / Surround	OK USB/Audio	5
Power CD/FM	Shift + Power	OK	OK
CD/FM	3	OK CD/FM	Shift + OK
Dock	Green / APP / Repeat	Play USB/Audio I	Shift + Play /
USB/Audio In	8	Play/Pause CD/FM	Pause / Step / Freeze
Preset/Album Up USB/Audio In	CH+ / Page+	Play/Pause	Play / Slow
Preset/Album	Up	Vol +	Vol +
Preset/Album Up CD/FM	Shift + Up	Vol -	Vol -
Preset/Album Down USB/Audio	CH- / Page-	Menu USB/Audio	Shift + Display / Media
Preset/Album	Down	Stop USB/Audio I	>> / Tune+
Preset/Album Down CD/FM	Shift + Down	Stop CD/FM	Shift + Stop /
I << USB/Audio In	Shift + I << / Preset-	Menu CD/FM	D. Menu / Top
I <<	I << / Preset-	Stop	Stop / Hold
I << CD/FM	Left	Menu	Menu / Home
>>I USB/Audio In	Shift + >>I / Preset+	Display	Display / Media

Original		Replacement		Original	Replacement
DISPLAY	Display CD/FM	FORMAT PICTURE	Picture / Format		
DISPLAY	Display USB/Audio In	ANGLE INFO	Info / Angle		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
SHUFFLE REPEAT	Repeat Shuffle CD/FM	RDS AV INPUT	AV / Input / RDS		
SHUFFLE REPEAT	Repeat/Shuffle	TUNE-	<< / Tune-		
SHUFFLE REPEAT	Repeat/Shuffle USB/Audio In	RETURN BACK	Back / Return		
PROG	Prog CD/FM	OPT-TOOLS SETUP	Setup / OPT /		
PROG	Prog	GOTO TEXT	Text / Goto		
PROG	Prog USB/Audio I	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
SOUND	Sound	TITLE SOUND	Sound / Title		
CLOCK	Clock	Prime Video RANDOM	Blue / Prime Video / Random		
TIMER SLEEP	Sleep/Timer	TIMER SLEEP	Sleep / Timer		