Original		Replacement	
	Power		Power
	Lock	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
SEL	SEL	MEDIA DISPLAY	Display / Media
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
+	+	+ CH PAGE	CH+ / Page+
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
—	-	CH PAGE —	CH- / Page-
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
X	X	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
	O	PROGRAM TV/ RADIO	TV/Radio /
	Rec	REC MODE	Rec / Rec Mode
OTR	OTR	SURROUND	Eject / Surround
	Play Reverse		Left
	Play	SLOW	Play / Slow
	N>/O	HOME MENU	Menu / Home
	<<?	TUNE-	<< / Tune-
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	<-/ >>	TUNE+	>> / Tune+
	[+]	ANGLE INFO	Info / Angle
	>I </ +	OK	OK
	I I >		Up
	>]	RDS AV INPUT	AV / Input / RDS
000	0000	TOP MENU D.MENU	D. Menu / Top
	↔	TIMER SLEEP	Sleep / Timer
	Recall	RETURN BACK	Back / Return

Original		Replacement		Original	Replacement
	Vol +	VOL +	Vol +		
SP/LP	SP/LP	FORMAT PICTURE	Picture / Format		
	O=	SIZE ZOOM	Zoom / Size		
	Sound	TITLE SOUND	Sound / Title		
	Vol -	VOL −	Vol -		
	←	PRESET- ⏮	I<< / Preset-		
	→	PRESET+ ⏭	>>I / Preset+		
	-->>	EQ SUBTITLE	Subtitle / EQ		
NICAM	Nicam	LANG I/II AUDIO	Audio / Lang I/II		
	[=]	GOTO TEXT	Text / Goto		
	X (Yellow)	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	♦	▼	Down		
	[i]	LIST SMART	Smart / List		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		

Original		Replacement	
	Power		Power
	<<< / ?	TUNE-	<< / Tune-
	<-/ >>	TUNE+	>> / Tune+
	Sound	TITLE SOUND	Sound / Title
	♦	SIZE ZOOM	Zoom / Size
	[=]	GOTO TEXT	Text / Goto
	>]	RDS AV INPUT	AV / Input / RDS
	N>/ O	HOME MENU	Menu / Home
	[+]	ANGLE INFO	Info / Angle
	>I </ +	OK	OK
	X(Yellow)	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Vol +	+ VOL	Vol +
	[i]	LIST SMART	Smart / List
	+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
SEL	SEL	MEDIA DISPLAY	Display / Media
-/--	-	CH PAGE −	CH- / Page-

Original		Replacement	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	- / - -	-/-- GUIDE EPG	Guide / EPG / - / - -
0	0	HDMI - SAT 0	0
X	X	PC FAV MARKER	Fav / Marker / PC
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random