Original		Replacement	
STANDBY /ON	Power		Power
SLEEP/ TIMER	Sleep/Timer	TIMER SLEEP	Sleep / Timer
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CD	Play/Pause CD	SLOW	Play / Slow
LINE	Line	EQ SUBTITLE	Subtitle / EQ
TAPE	<> Tape	RETURN BACK	Back / Return
FM/AM	FM/AM	PROGRAM TV/ RADIO	TV/Radio /
	I<<<-	PRESET-	I<< / Preset-
	Stop	HOLD	Stop / Hold
	>>I / +	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6

Original		Replacement	
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
>10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
10/0	10/0	HDMI - SAT 0	0
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REC MENU	Rec Menu	REC MODE	Rec / Rec Mode
PGM	PGM	LIST SMART	Smart / List
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PLAY MODE	Play Mode	SURROUND	Eject / Surround
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
	Up		Up
	Down		Down
	Left		Left
	Right		Right
ENTER	Enter	OK	OK

Original	Replacement	Original	Replacement
Vol +	Vol +		
Vol -	Vol -		