Mandis shop

Samsung BP5900135A

Original		Replacement	
POWER	Power		Power
AUTO	Auto	LIST SMART	Smart / List
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
MENU	Menu	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
	Up		Up
	Left		Left
	Enter	OK	OK
	Right		Right
	Down		Down
V.KEY-STONE	V. Keystone+	CH PAGE	CH+ / Page+
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL	Vol +	VOL	Vol +
V.KEY-STONE	V. Keystone-	CH PAGE	CH- / Page-
VOL	Vol -	VOL	Vol -
INSTALL	Install	TOP MENU D.MENU	D. Menu / Top
QUICK	Quick	MEDIA DISPLAY	Display / Media

Original		Replacement	
INFO	Info	ANGLE INFO	Info / Angle
BLANK	Blank	OPT-TOOLS SETUP	Setup / OPT /
STILL	Still	STEP-FREEZE	Pause / Step / Freeze
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
P.SIZE	P. Size	SIZE ZOOM	Zoom / Size
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format

https://remotes.a/e/Samsung/1054962/replacement-remote-control-for-Samsung-TV-BP59-00135A.htm