Original		Replacement	
	Power		Power
DS	DS	APP MEDIA	Media
TV/	Tv/Source	TIMER AV	AV
WIDE	Wide	PICTURE FORMAT	Format
	Mute	MUTE	Mute
P P D/A	D/A / P↔P	FAV PRE-CH	Pre Ch
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--/[≡o]	SHIFT + -/-- GUIDE	Shift + Guide

Original		Replacement	
CS	CS	HOME SMART	Smart
	[Y]/[≡?]	CLEAR EXIT	Exit
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
MENU	Menu/[≡i]	TOP MENU MENU	Menu
RETURN	Return/[≡x]	RETURN BACK	Back
INFO	Info	DISPLAY INFO	Info
GUIDE	Guide	-/-- GUIDE	Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok

Original		Replacement	
+	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
	Rec	REC MODE	Rec
	Pause		Pause
	Power Down	SHIFT +	Shift + Power
	Stop		Stop
	Play	PLAY MODE	Play
PREV	<<		<<
NEXT	>>		>>
SURROUND	Surround	SOUND DUAL	Dual
BASS	Bass	SETTINGS OPT	Options
	→ ←	ECO 3D	3D
▽A·B	▼/ A/ B	DISC NAV LIST	List
SUBTITLE	Subtitle	AD SUBT	Subt
	[≡♦]	SEARCH TV/R	TV/ R
	[≡+]	E-MANUAL D.MENU	D. Menu
TXT/TV	TXT/ TV	REPEAT TEXT	Text

Original	Replacement

Original		Replacement	
	Power Down		Power
	Menu/ [≡i]		Menu
	Enter		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Pause		Pause
	Stop		Stop
	Play		Play
	Prev		I <<
	Next		>>I

Original	Replacement