Original		Replacement	
ON/OFF	On/Off		Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TV GUIDE	Tv Guide	-/-- GUIDE	Guide
	Recall	FAV PRE-CH	Pre Ch
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
PICTURE	Picture	PICTURE FORMAT	Format

Original		Replacement	
SOUND	Sound	SOUND DUAL	Dual
SOURCE	Source	TIMER AV	AV
+ CH	CH+	+ CH	Ch +
CH −	CH-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
BACK	Back	RETURN BACK	Back
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	Ok	OK	Ok
INFO	Info	DISPLAY INFO	Info
TEXT	Text	REPEAT TEXT	Text
SUBTITLE	Subtitle	AD SUBT	Subt
TV	Tv	SEARCH TV/R	TV/R

Original		Replacement		Original		Replacement	
	YouTube	APP MEDIA	Media				
	Netflix	HOME SMART	Smart				
	NET+	SHIFT + APP MEDIA	Shift + Media				
	Rec	REC MODE	Rec				
	I<<	<<I	I<<				
	>>I	>>I	>>I				
	Stop	■	Stop				
	Rec List	DISC NAV LIST	List				
	<<	<<	<<				
	>>	>>	>>				
	Play	PLAY MODE ▶	Play				
	Pause	II	Pause				
	Red/ Goto	A	Red				
	Green/ A-B	B	Green				
	Yellow/ 3D	C	Yellow				
	Blue/ Repeat	D	Blue				