Original		Replacement	
STANDBY	Standby		Power
	Lock	HOME SMART	Smart
TIMER ON/OFF	Timer On/Off	PROG SLEEP	Sleep
AUDIO OUT	Audio Out	SOUND DUAL	Dual
SKIP SEARCH	Skip Search	PICTURE FORMAT	Format
ZERO BACK	Zero Back	RETURN BACK	Back
MENU	Menu	TOP MENU MENU	Menu
SET	Set	SETTINGS OPT	Options
SV/V+ /TIMER	SV/V+/Timer	FAV PRE-CH	Pre Ch
CLEAR	Clear	CLEAR EXIT	Exit
	UP		Up
	Down		Down
	Right		Right
	Left		Left
1	1	1	1
2	2	2	2
3	3	3	3

Original		Replacement	
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
AM/PM	-/--/AM/PM	-/-- GUIDE	Guide
INPUT SELECT	Input Select	TIMER AV	AV
MODE OSD	Mode OSD	AD SUBT	Subt
DISPLAY	Display	DISPLAY INFO	Info
CHANNEL	Channel Up	+ CH	Ch +
CHANNEL	Channel Down	CH −	Ch -
REW	<<	<<	<<
PLAY/X2	Play	PLAY MODE ▶	Play
FF	>>	>>	>>
REC	Rec	REC MODE	Rec

Original		Replacement		Original	Replacement
STOP	Stop	■	Stop		
PAUSE/STILL	Pause/Still	II	Pause		
TAPE SPEED	Tape Speed	ECO 3D	3D		
SLOW	I>Slow	DISC NAV LIST	List		
DPSS	<DPSS/-	⏮	I<<		
DPSS	DPSS >/+	⏭	>>I		
TV/VCR	TV/VCR	SEARCH TV/R	TV/R		
OPERATE	Tv Operate	SHIFT + ⏻	Shift + Power		
INPUT SELECT	Input Select T	SHIFT + TIMER AV	Shift + AV		
CH▲	CH+ Tv	SHIFT + + CH	Shift + Ch +		
CH▼	CH- Tv	SHIFT + CH −	Shift + Ch -		
VOL⊕	Vol + Tv	+ VOL	Vol +		
VOL⊖	Vol - Tv	VOL −	Vol -		