Original		Replacement	
	Power		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	Mute	DIMMER MUTE	Mute / Dimmer
0	0	HDMI - SAT 0	0
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
VOL +	Vol +	VOL +	Vol +
	Colours	FORMAT PICTURE	Picture / Format
CH	Ch+	CH PAGE +	CH+ / Page+

Original		Replacement	
VOL −	Vol -	VOL −	Vol -
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
CH −	Ch-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
OK	Ok	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
prime video	Prime Video	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
YouTube	YouTube	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
Play	FPlay	SHIFT + SLOW ▶	Shift + Play /
MTS	MTS	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement		Original	Replacement
TEXT	Text	GOTO TEXT	Text / Goto		
SUB	Sub	EQ SUBTITLE	Subtitle / EQ		
TV	TV	PROGRAM TV/RADIO	TV/Radio /		
▶II	Play	SLOW ▶	Play / Slow		
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
■	Stop	HOLD ■	Stop / Hold		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		