Original	Replacement	Original	Replacement
Power	Power	Mute	Mute / Dimmer
Open / Close	Eject / Surround	Play / Pause	Play / Slow
1	1	Stop	Stop / Hold
2	2	I <<	I << / Preset-
3	3	Vol +	Vol +
4	4	>>I	>>I / Preset+
5	5	<<	<< / Tune-
6	6	Vol -	Vol -
7	7	>>	>> / Tune+
8	8	Title	Sound / Title
9	9	Up	Up
0 / 10	0	Left	Left
10+	Guide / EPG / -/--	Enter	OK
Setup	Setup / OPT /	Right	Right
Display	Display / Media	Down	Down
Repeat	Green / APP / Repeat	Menu Ripping	Menu / Home
Angle	Info / Angle	Slow	Shift + Play / Slow

Original		Replacement		Original	Replacement
RETURN	Return	RETURN BACK	Back / Return		
STEP	Step	STEP · FREEZE	Pause / Step / Freeze		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat		