Mandis shop

Sony RMF-TX201E

Original		Replacement	
	Power		Power
	Source	TIMER AV	AV
DIGITAL/ ANALOG	Digital/Analog	PICTURE FORMAT	Format
TV/ RADIO	Tv/Radio	SEARCH TV/R	TV/R
SYNC MENU	Sync Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
1	1	1	1
2abc	2	2	2
3def	3	3	3
4ghi	4	4	4
5jkl	5	5	5
6mno	6	6	6
7pqrs	7	7	7
8tuv	8	8	8
9wxyz	9	9	9
0	0	0	0
	[i+]/[?]	DISPLAY INFO	Info

Original		Replacement	
	[≡]	REPEAT TEXT	Text
Google Play	Google Play	SHIFT + HOME SMART	Shift + Smart
NETFLIX	Netflix	APP MEDIA	Media
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
TV	TV	SETTINGS OPT	Options
ACTION MENU	Action Menu	E-MANUAL D.MENU	D. Menu
GUIDE	Guide	-/-- GUIDE	Guide
BACK	Back	RETURN BACK	Back
DISCOVER	Discover	PROG SLEEP	Sleep
HOME	Home	HOME SMART	Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
	OK	OK	Ok
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
	Recall	FAV PRE-CH	Pre Ch
PROG +	Prog+	+ CH	Ch +
–	Prog-	CH –	Ch -
AUDIO	Audio	SOUND DUAL	Dual
	[. . .]	AD SUBT	Subt
	<<	<<	<<
	Play	PLAY MODE	Play
	>>	>>	>>
	I <<	I <<	I <<
	Pause		Pause
	>>I	>>I	>>I
REC	Rec	REC MODE	Rec
	Stop		Stop

Original		Replacement	
HELP	Help	ECO 3D	3D
TITLE LIST	Title List	DISC NAV LIST	List