Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
	[ ]	HOME SMART	Smart
	[≡]	REPEAT TEXT	Text
	Input	TIMER AV	AV
	Output	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/-- GUIDE	Guide

Original		Replacement	
C	C	FAV PRE-CH	Pre Ch
	[*]	SEARCH TV/R	TV/R
	[↔*]	AD SUBT	Subt
	[↑*]	DISC NAV LIST	List
	[↑]	SETTINGS OPT	Options
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	[≡+]	ECO 3D	3D
	[+]	DISPLAY INFO	Info
SAT	SAT	RETURN BACK	Back
PROGR +	Prog+	+ CH	Ch +
–	Prog-	CH –	Ch -
+	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
	Picture	PICTURE FORMAT	Format

Original		Replacement		Original	Replacement
♪	♪	SOUND DUAL	Dual		
←	←		Left		
Up/ +	Up/ +		Up		
Down/ -	Down/ -		Down		
MENU	Menu	TOP MENU MENU	Menu		
OK	OK	OK	Ok		
Power MDP	Power MDP	SHIFT +	Shift + Power		
>> MDT	>> MDT		>>		
Play MDT	Play MDT	PLAY MODE	Play		
<< MDT	<< MDT		<<		
Stop MDT	Stop MDT		Stop		
Pause MDT	Pause MDT		Pause		
PROGR +	Prog+ MDT	SHIFT +	Shift + Ch +		
PROGR −	Prog- MDT	SHIFT +	Shift + Ch -		

Original		Replacement		Original	Replacement
	Power		Power		
PROGR +	Prog+	CH +	Ch +		
PROGR −	Prog-	CH −	Ch -		
	>>		>>		
	Play	PLAY MODE	Play		
	<<		<<		
	Stop		Stop		
	Pause		Pause		
	Rec	REC MODE	Rec		

Original		Replacement		Original	Replacement
	Power		Power		
PROGR +	Prog+	CH +	Ch +		
PROGR −	Prog-	CH −	Ch -		
	>>		>>		
	Play	PLAY MODE	Play		
	<<		<<		
	Stop		Stop		
	Pause		Pause		
	Rec	REC MODE	Rec		

Original		Replacement	
	Power		Power
PROGR +	Prog+	CH +	Ch +
PROGR −	Prog-	CH −	Ch -
	>>		>>
	Play	PLAY MODE	Play
	<<		<<
	Stop		Stop
	Pause		Pause
	Rec	REC MODE	Rec

Original	Replacement