Original	Replacement	Original	Replacement
Power Receiver	Power	Surround	Eject / Surround
Power Audio	Red / Netflix / Search	3 Stereo	Audio / Lang I/II
Power TV	Blue / Prime Video / Random	Help	Info / Angle
Power VCR	Shift + Red / Netflix /	Disc	Smart / List
Power VDP	Yellow / YouTube / Repeat	Disc Enter	Display / Media
Power CD	Green / APP / Repeat	TV / AV	AV / Input / RDS
Power TAPE	Shift + Green / APP /	TUNER 1	1
TUNER	Shift + 6	TUNER 2	2
CD	Shift + 3	TUNER 3	3
TAPE MONITOR	Shift + 5	Direct Tuning	Menu / Home
TV/VCR 2	Shift + 1	TV Vol +	Shift + Vol +
VDP	Shift + 2	TUNER 4	4
VCR1	Shift + 4	TUNER 5	5
CH Level -	CH- / Page-	TUNER 6	6
CH Level +	CH+ / Page+	TUNER >=10	Guide / EPG / -/--
Test	Text / Goto	TV Vol -	Shift + Vol -
CH Select	Setup / OPT / Tools	TUNER 7	7

Original		Replacement		Original		Replacement	
8	TUNER 8	8	8				
9	TUNER 9	9	9				
0	TUNER 0	0	0				
◀◀	TAPE MON <<	TUNE- ◀◀	<< / Tune-				
▶▶	TAPE MON >>	TUNE+ ▶▶	>> / Tune+				
DECK1/2	TAPE MON Deck	OK	OK				
◀	TAPE MON Rev.	◀	Left				
⏸	TAPE MON	STEP-FREEZE ⏸	Pause / Step / Freeze				
■	TAPE MON Stop	HOLD ■	Stop / Hold				
▶	TAPE MON Play	SLOW ▶	Play / Slow				
▶	TAPE MON Play	▶	Right				
MUTING	Muting	DIMMER MUTE	Mute / Dimmer				
VOLUME –	Volume-	VOL –	Vol -				
VOLUME +	Volume+	VOL +	Vol +				

Original	Replacement	Original	Replacement
Power Receiver	Power	Surround	Eject / Surround
Power Audio	Red / Netflix / Search	3 Stereo	Audio / Lang I/II
Power TV	Blue / Prime Video / Random	Help	Info / Angle
Power VCR	Shift + Red / Netflix /	Disc	Smart / List
Power VDP	Yellow / YouTube / Repeat	Disc Enter	Display / Media
Power CD	Green / APP / Repeat	TV / AV	AV / Input / RDS
Power TAPE	Shift + Green / APP /	CD 1	1
TUNER	Shift + 6	CD 2	2
CD	Shift + 3	CD 3	3
TAPE MONITOR	Shift + 5	Direct Tuning	Menu / Home
TV/VCR 2	Shift + 1	TV Vol +	Shift + Vol +
VDP	Shift + 2	CD 4	4
VCR1	Shift + 4	CD 5	5
CH Level -	CH- / Page-	CD 6	6
CH Level +	CH+ / Page+	CD >=10	Guide / EPG / -/--
Test	Text / Goto	TV Vol -	Shift + Vol -
CH Select	Setup / OPT / Tools	CD 7	7

Original		Replacement		Original	Replacement
8	CD 8	USB 8	8		
9	CD 9	BLUETOOTH 9	9		
0	CD 0	HDMI - SAT 0	0		
⏮	CD I <<	PRESET- ⏮	I << / Preset-		
⏭	CD >>I	PRESET+ ⏭	>>I / Preset+		
◀◀	CD <<	TUNE- ◀◀	<< / Tune-		
▶▶	CD >>	TUNE+ ▶▶	>> / Tune+		
⏸	CD Pause	STEP - FREEZE ⏸	Pause / Step / Freeze		
■	CD Stop	HOLD ■	Stop / Hold		
▶	CD Play	SLOW ▶	Play / Slow		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
− VOLU	Volume-	VOL −	Vol -		
LUME +	Volume+	+ VOL	Vol +		

Original	Replacement	Original	Replacement
Power Receiver	Power	Surround	Eject / Surround
Power Audio	Red / Netflix / Search	3 Stereo	Audio / Lang I/II
Power TV	Blue / Prime Video / Random	Help	Info / Angle
Power VCR	Shift + Red / Netflix /	Disc	Smart / List
Power VDP	Yellow / YouTube / Repeat	Disc Enter	Display / Media
Power CD	Green / APP / Repeat	TV / AV	AV / Input / RDS
Power TAPE	Shift + Green / APP /	VDP 1	1
TUNER	Shift + 6	VDP 2	2
CD	Shift + 3	VDP 3	3
TAPE MONITOR	Shift + 5	Direct Tuning	Menu / Home
TV/VCR 2	Shift + 1	TV Vol +	Shift + Vol +
VDP	Shift + 2	VDP 4	4
VCR1	Shift + 4	VDP 5	5
CH Level -	CH- / Page-	VDP 6	6
CH Level +	CH+ / Page+	VDP >=10	Guide / EPG / -/--
Test	Text / Goto	TV Vol -	Shift + Vol -
CH Select	Setup / OPT / Tools	VDP 7	7

Original		Replacement		Original	Replacement
8	VDP 8	USB 8	8		
9	VDP 9	BLUETOOTH 9	9		
0	VDP 0	HDMI - SAT 0	0		
⏮	VDP I <<	PRESET- ⏮	I << / Preset-		
⏭	VDP >>I	PRESET+ ⏭	>>I / Preset+		
◀◀	VDP <<	TUNE- ◀◀	<< / Tune-		
▶▶	VDP >>	TUNE+ ▶▶	>> / Tune+		
⏸	VDP Pause	STEP - FREEZE ⏸	Pause / Step / Freeze		
■	VDP Stop	HOLD ■	Stop / Hold		
▶	VDP Play	SLOW ▶	Play / Slow		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
VOLUME −	Volume-	VOL −	Vol -		
VOLUME +	Volume+	+ VOL	Vol +		

Original	Replacement	Original	Replacement
Power Receiver	Power	Surround	Eject / Surround
Power Audio	Red / Netflix / Search	3 Stereo	Audio / Lang I/II
Power TV	Blue / Prime Video / Random	Help	Info / Angle
Power VCR	Shift + Red / Netflix /	Disc	Smart / List
Power VDP	Yellow / YouTube / Repeat	Disc Enter	Display / Media
Power CD	Green / APP / Repeat	TV / AV	AV / Input / RDS
Power TAPE	Shift + Green / APP /	VCR 1 1	1
TUNER	Shift + 6	VCR 1 2	2
CD	Shift + 3	VCR 1 3	3
TAPE MONITOR	Shift + 5	Direct Tuning	Menu / Home
TV/VCR 2	Shift + 1	TV Vol +	Shift + Vol +
VDP	Shift + 2	VCR 1 4	4
VCR1	Shift + 4	VCR 1 5	5
CH Level -	CH- / Page-	VCR 1 6	6
CH Level +	CH+ / Page+	VCR 1 >=10	Guide / EPG / -/--
Test	Text / Goto	TV Vol -	Shift + Vol -
CH Select	Setup / OPT / Tools	VCR 1 7	7

Original		Replacement		Original	Replacement
8	VCR 1 8	USB 8	8		
9	VCR 1 9	BLUETOOTH 9	9		
0	VCR 1 0	HDMI - SAT 0	0		
◀◀	VCR 1 <<	TUNE- ◀◀	<< / Tune-		
▶▶	VCR 1 >>	TUNE+ ▶▶	>> / Tune+		
❚❚	VCR 1 Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze		
■	VCR 1 Stop	HOLD ■	Stop / Hold		
▶	VCR 1 Play	SLOW ▶	Play / Slow		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
− VOLU	Volume-	VOL −	Vol -		
LUME +	Volume+	+ VOL	Vol +		