| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| | Input | RDS AV INPUT | AV / Input / RDS | ATV/ DTV | ATV/ DTV | PROGRAM TV/ RADIO | TV/ Radio / |
| | Power | | Power | | Vol + | VOL + | Vol + |
| | [▼] | PC FAV MARKER | Fav / Marker / PC | | [ ≡ ] / [ i + ] | ANGLE INFO | Info / Angle |
| TEXT | Text | GOTO TEXT | Text / Goto | P | PR+ | CH PAGE + | CH+ / Page+ |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ | | Vol - | VOL − | Vol - |
| | O) / I / II | LANG I/II AUDIO | Audio / Lang I/II | | Mute | DIMMER MUTE | Mute / Dimmer |
| 1 | 1 | TV 1 | 1 | P | PR- | CH PAGE − | CH- / Page- |
| 2 | 2 | DVD 2 | 2 | QUICK | Quick | LIST SMART | Smart / List |
| 3 | 3 | CD - STB 3 | 3 | GUIDE | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 4 | 4 | VIDEO 4 | 4 | | Up | | Up |
| 5 | 5 | TAPE 5 | 5 | EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| 6 | 6 | TUNER 6 | 6 | | Left | | Left |
| 7 | 7 | AUX - HDD 7 | 7 | OK | OK | OK | OK |
| 8 | 8 | USB 8 | 8 | | Right | | Right |
| 9 | 9 | BLUETOOTH 9 | 9 | MENU | Menu | HOME MENU | Menu / Home |
| AD | AD | TITLE SOUND | Sound / Title | | Down | | Down |
| 0 | 0 | HDMI - SAT 0 | 0 | RETURN | Return | RETURN BACK | Back / Return |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Red | Red / Netflix / Search | | |
| Green | Green / APP / Repeat | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue | Blue / Prime Video / Random | | |
| [ ≡?] | Display / Media | | |
| [ ≡+] | Stop / Hold | | |
| [ ≡♦] | Zoom / Size | | |
| Timer / [ ≡x] | Sleep / Timer | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |