Original	Replacement	Original	Replacement
Power	Power	Exit	Exit
Mute	Mute	Up	Up
1	1	Down	Down
2	2	Right	Right
3	3	Left	Left
4	4	OK	Ok
5	5	P+	Ch +
6	6	P-	Ch -
7	7	Vol +	Vol +
8	8	Vol -	Vol -
9	9	Red	Red
0	0	Green	Green
Recall	Pre Ch	Yellow	Yellow
Input	AV	Blue	Blue
Menu	Menu	♪	Shift + Dual
[<>]	Format	PC Input	Smart
-[/] ←	Subt	[i +]	Info

Original		Replacement		Original	Replacement
	O) I / I I	SOUND DUAL	Dual		
	[▼]	SEARCH TV/R	TV/ R		
	[≡] / [/ ≡] / [ ]	REPEAT TEXT	Text		
	[≡i]	DISC NAV LIST	Li st		
	[≡O]	RETURN BACK	Back		
	[≡?]	-/-- GUIDE	Gui de		
	[≡+]	APP MEDIA	Medi a		
	[≡♦]	ECO 3D	3D		
	[O] / [≡x]	ZOOM ⏏	Ej ect		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Menu DVD		Menu
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
	OK		Ok
	P+		Ch +
	P-		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Pause/Step		Pause
	Play		Play
	<<		<<
	>>		>>
	Open/Close		Eject
	Stop		Stop
	I <<		I <<
	>>I		>>I

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Input	AV
Up	Up
Down	Down
P+	Ch +
P-	Ch -
Pause/Step	Pause

Original	Replacement
Play	Play
<<	<<
>>	>>
Eject	Eject
Stop	Stop
I <<	I <<
>>I	>>I