Original	Replacement	Original	Replacement
Power Source	SHIFT + Shift + Power	Audio 2	SHIFT + DVD 2 Shift + 2
Power Receiver	Power	Tuner	SHIFT + TUNER 6 Shift + 6
HDMI 1	NETFLIX SEARCH Red / Netflix / Search	USB	SHIFT + USB 8 Shift + 8
HDMI 2	APP REPEAT Green / APP / Repeat	Net	SHIFT + VIDEO 4 Shift + 4
HDMI 3	YouTube REPEAT A-B Yellow / YouTube / Repeat	Phono	SHIFT + CD-STB 3 Shift + 3
HDMI 4	Prime Video RANDOM Blue / Prime Video / Random	Party	PROGRAM TV/RADIO TV/Radio /
HDMI 5	SHIFT + TAPE 5 Shift + 5	HDMI Out	RDS AV INPUT AV / Input / RDS
HDMI 6	SHIFT + HDMI-SAT 0 Shift + 0	BD/DVD Scene	SHIFT + ▲ Shift + Up
HDMI 7	SHIFT + BLUETOOTH 9 Shift + 9	TV Scene	SHIFT + ◀ Shift + Left
V-AUX	SHIFT + AUX-HDD 7 Shift + 7	NET Scene	SHIFT + ▶ Shift + Right
AV 1	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	Radio Scene	SHIFT + ▼ Shift + Down
AV 2	SHIFT + APP REPEAT Shift + Green / APP /	Program Up	CH PAGE + CH+ / Page+
AV 3	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /	Volume+	VOL + Vol +
AV 4	SHIFT + Prime Video RANDOM Shift + Blue / Prime	Program Down	CH PAGE − CH- / Page-
AV 5	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--	Mute	DIMMER MUTE Mute / Dimmer
AV 6	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC	Volume-	VOL − Vol -
Audio 1	SHIFT + TV 1 Shift + 1	Top Menu	TOP MENU D.MENU D. Menu / Top Menu

Original		Replacement	
POP-UP/MENU	Pop-Up Menu	HOME MENU	Menu / Home
ON SCREEN	On Screen	GOTO TEXT	Text / Goto
	Up		Up
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MODE	Mode	LIST SMART	Smart / List
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
BAND	Play/Band	SLOW	Play / Slow
	<< Tuning	TUNE-	<< / Tune-
	Tuning >>	TUNE+	>> / Tune+
	I<< Preset	PRESET-	I<< / Preset-

Original		Replacement	
	Preset >>I	PRESET+	>>I / Preset+
MOVIE	Movie	TITLE SOUND	Sound / Title
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
SUR. DECODE	Sur. Decode	SURROUND	Eject / Surround
STRAIGHT	Straight	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ENHANCER	Enhancer	EQ SUBTITLE	Subtitle / EQ
PURE DIRECT	Pure Direct	SIZE ZOOM	Zoom / Size
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Replacement		Original	Replacement
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
MEMORY +10	+10/ Memory	-/-- GUIDE EPG	Guide / EPG / -/--		
ENT	ENT.	PC FAV MARKER	Fav / Marker / PC		

Original	Replacement	Original	Replacement
Power Source	SHIFT + Shift + Power	Audio 2	SHIFT + DVD 2 Shift + 2
Power Receiver	Power	Tuner	SHIFT + TUNER 6 Shift + 6
HDMI 1	NETFLIX SEARCH Red / Netflix / Search	USB	SHIFT + USB 8 Shift + 8
HDMI 2	APP REPEAT Green / APP / Repeat	NET	SHIFT + VIDEO 4 Shift + 4
HDMI 3	YouTube REPEAT A-B Yellow / YouTube / Repeat	PHONO	SHIFT + CD-STB 3 Shift + 3
HDMI 4	Prime Video RANDOM Blue / Prime Video / Random	PARTY	PROGRAM TV/RADIO TV/Radio /
HDMI 5	SHIFT + TAPE 5 Shift + 5	HDMI OUT	RDS AV INPUT AV / Input / RDS
HDMI 6	SHIFT + HDMI-SAT 0 Shift + 0	BD/DVD Scene	SHIFT + ▲ Shift + Up
HDMI 7	SHIFT + BLUETOOTH 9 Shift + 9	TV Scene	SHIFT + ◀ Shift + Left
V-AUX	SHIFT + AUX-HDD 7 Shift + 7	NET Scene	SHIFT + ▶ Shift + Right
AV 1	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	Radio Scene	SHIFT + ▼ Shift + Down
AV 2	SHIFT + APP REPEAT Shift + Green / APP /	VOLUME+	VOL + Vol +
AV 3	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /	MUTE	DIMMER MUTE Mute / Dimmer
AV 4	SHIFT + Prime Video RANDOM Shift + Blue / Prime	VOLUME-	VOL - Vol -
AV 5	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--	TOP MENU	TOP MENU D.MENU D. Menu / Top
AV 6	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC	POP-UP MENU	HOME MENU Menu / Home
Audio 1	SHIFT + TV 1 Shift + 1	ON SCREEN	GOTO TEXT Text / Goto

Original		Replacement	
	Up		Up
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MODE	Mode	LIST SMART	Smart / List
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
BAND	Play/Band	SLOW	Play / Slow
	<< Tuning	TUNE-	<< / Tune-
	Tuning >>	TUNE+	>> / Tune+
	I<< Preset	PRESET-	I<< / Preset-
	Preset >>I	PRESET+	>>I / Preset+
INFO	Info	ANGLE INFO	Info / Angle

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
MEMORY +10	+10/Memory	-/-- GUIDE EPG	Guide / EPG / -/--
ENT	ENT	PC FAV MARKER	Fav / Marker / PC