# Mandis shop

Yamaha FSR80

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | YSP Position C | OK |
| TV | 1 | YSP Position R | Right |
| BD/DVD | 2 | Subwoofer+ | CH+ / Page+ |
| Analog | 3 | Volume+ | Vol + |
| Portable | 4 | Subwoofer- | CH- / Page- |
| Bluetooth | 9 | Mute | Mute / Dimmer |
| Bluetooth | Fav / Marker / PC | Volume- | Vol - |
| Clear Voice | Exit / Cancel / Clear | CH Level | AV / Input / RDS |
| Univolume | Smart / List | Tv Remote Control Learn | TV/Radio / |
| Audio Delay | Audio / Lang I/II | Tv Remote Control Repeater | Zoom / Size |
| Movie | Red / Netflix / Search | | |
| Music | Green / APP / Repeat | | |
| Sports | Yellow / YouTube / Repeat | | |
| Game | Blue / Prime Video / Random | | |
| Tv Program | Guide / EPG / -/-- | | |
| Stereo | Sound / Title | | |
| YSP Position L | Left | | |

https://remotes.at/en/Yamaha/1632-604-replacement-remote-control-for-Yamaha-FSR80-ZG80760.htm