






















Original	Replacement	Original	Replacement
	Power		Mute
	1		Mute
	2		Media
	3		Exit
	4		Up
	5		Down
	6		Right
	7		Left
	8		Ok
	9		Menu
	0		Menu
	Source		Tv/FAV/Radio/Set
	ATV/DTV/Content Menu		Red
	Vol+		Green
	Vol-		Yellow
	P+		Blue
	P-		[<>]
			Format
			3D
			Subt









































































	Original	Replacement		Original	Replacement
	Text	 Text			
	II/II>/[▼]	 Pause			
	[i+]/[≡i]	 Info			
	O)I/II	 Dual			
	Stop	 Stop			
	Play/[≡o]	 Play			
	Eject	 Eject			
	I<</[≡?]	 I<<			
	<<[/[≡+]	 <<			
	>>/[≡♦]	 >>			
	>>I/[O]/[≡X]	 >>I			
	AD	 Shift + Subt			
	Audio	 Shift + Dual			





Original		Replacement		Original		Replacement	
	←[/]→		3D		Menu/DVD		Menu
	Power		Power		Tv/FAV/Radio/Set		TV/R
	1		1		Guide/Top		Guide
	2		2		[<>]		Format
	3		3		Text		Text
	4		4		Subtitle		Subt
	5		5		O) /II		Dual
	6		6		[i+]/[≡i]		Info
	7		7		OK		Ok
	8		8		Up		Up
	9		9		Down		Down
	0		0		Right		Right
	Source		AV		Left		Left
	Mute		Mute		/II>/[▼]		Pause
	Vol+		Vol +		Play/[≡o]		Play
	Vol-		Vol -		Stop		Stop
	Exit/Return		Exit		Eject		Eject














































Original	Replacement	Original	Replacement
  <</[≡?]	  <<		
 <</[≡+]	 <<		
 >>/[≡◆]	 >>		
 >> /[O]/[≡X]	 >>		
AUDIO TEXT Audio	 +  Shift + Dual		





Original	Replacement	Original	Replacement
	Power		Power
	←[/]→		3D
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Source		AV
	ATV/DTV/Content Menu		Smart
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +

Original	Replacement	Original	Replacement
	P-		Ch -
	Mute		Mute
	Guide/Top		Guide
	Exit/Return		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu/DVD		Menu
	Tv/FAV/Radio/Set		TV/R
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text		Text
	[<>]		Format





Original	Replacement	Original	Replacement
	[i+]/[≡i]		Info
	II/II>/[▼]		Pause
	Subtitle		Subt
	O)/II		Dual
	Play/[≡o]		Play
	Stop		Stop
	Eject		Eject
	I<</[≡?]		I<<
	<</[≡+]		<<
	>>/[≡◇]		>>
	>>I/[O]/[≡X]		>>I
	Audio		Shift + Dual
	AD		Shift + Subt

