







































































Original	Replacement	Original	Replacement
 Power	 Power	 9	 9
 EPG	 Guide / EPG / -/--	 Zoom	 Zoom / Size
 Teletext	 Text / Goto	 0	 0
 Select	 Smart / List	 Goto	 Shift + Text /
 Confirm	 D.Menu / Top	 i/Display	 Display / Media
 Title	 Sound / Title	 Guide	 Shift + Guide / EPG / -/--
 Eject	 Eject / Surround	 Up	 Up
 Menu	 Menu / Home	 Left	 Left
 Option	 Shift + Setup / OPT / Tools	 OK	 OK
 1	 1	 Right	 Right
 2	 2	 Rec	 Rec / Rec Mode
 3	 3	 Down	 Down
 4	 4	 Return	 Back / Return
 5	 5	 Vol-	 Vol-
 6	 6	 Vol+	 Vol+
 7	 7	 <<	 << / Tune-
 8	 8	 Stop	 Stop / Hold





Original	Replacement
Play	Play / Slow
>>	>> / Tune+
I<<	I<< / Preset-
I>/Slow	Info / Angle
Pausue/Step	Pause / Step / Freeze
>>I	>>I / Preset+
Source	AV / Input / RDS
Time Shift	Picture / Format
Repeat	Shift + Green / APP / REPEAT
aA/Subtitle	Subtitle / EQ
Setup	Setup / OPT /
Red	Red / Netflix / Search
Tv System	TV/Radio /
Green	Green / APP / Repeat
Audio	Audio / Lang I/II
Yellow	Yellow / YouTube / Repeat
Mute	Mute / Dimmer

Original	Replacement
Blue	Blue / Prime Video / Random

