








Original	Replacement
 Standby Receiver	 Power
 Standby Source	 Shift + Power
 HDMI1	 Shift + 1
 HDMI2	 Shift + 2
 HMDI3	 Shift + 3
 HDMI4	 Shift + 4
 HDMI5	 Shift + 5
 V-AUX	 Shift + Smart
 AV1	 Shift + 6
 AV2	 Shift + 7
 AV3	 Shift + 8
 AV4	 Shift + 9
 AV5	 Shift + Guide
 AV6	 Shift + 0
 Audio1	 Shift + Options
 Audio2	 Shift + Dual
 Tuner	 Red

Original	Replacement
 USB	 Green
 NET	 Yellow
 Phono	 Blue
 Party	 Pre Ch
 HDMI Out	 Exit
 BD/DVD Scene	 List
 TV Scene	 Shift + TV/R
 NET Scene	 Shift + Media
 Radio Scene	 3D
 PR+	 Ch +
 PR-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Top Menu	 Menu
 Pop Up/Menu	 D. Menu
 On Screen	 Eject





Original	Replacement
	 Options
	 Back
	 Shift + Info
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Smart
	 Stop
	 Pause
	 Play
	 <<
	 >>
	 I<<
	 >>I
	 Text










Original	Replacement
	 Dual
	 Subt
	 TV/R
	 Info
	 Sleep
	 AV
	 Format
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0













Original	Replacement
 Standby Receiver	 Power
 Standby Source	 Shift + Power
 HDMI1	 Shift + 1
 HDMI2	 Shift + 2
 HDMI3	 Shift + 3
 HDMI4	 Shift + 4
 HDMI5	 Shift + 5
 V-AUX	 Shift + Smart
 AV1	 Shift + 6
 AV2	 Shift + 7
 AV3	 Shift + 8
 AV4	 Shift + 9
 AV5	 Shift + Guide
 AV6	 Shift + 0
 Audio1	 Shift + Options
 Audio2	 Dual
 Tuner	 Red

Original	Replacement
 USB	 Green
 NET	 Yellow
 Phono	 Blue
 Party	 Pre Ch
 HDMI Out	 Exit
 BD/DVD Scene	 Text
 TV Scene	 AV
 NET Scene	 Format
 Radio Scene	 TV/R
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Top Menu	 Menu
 Pop Up/Menu	 D. Menu
 On Screen	 Eject
 Option	 Options
 Return	 Back





	Original	Replacement		Original	Replacement
	Display	 Shift + Info		2	 2
	Up	 Up		3	 3
	Down	 Down		4	 4
	Right	 Right		5	 5
	Left	 Left		6	 6
	Enter	 Ok		7	 7
	Mode	 Smart		8	 8
	Stop	 Stop		9	 9
	Pause	 Pause		0	 0
	Play/Band	 Play		+10/Memory	 Guide
	<< Tuning	 <<		ENT	 Media
	Tuning >>	 >>			
	I<< Preset	 I<<			
	Preset >>I	 >>I			
	Info	 Info			
	Sleep	 Sleep			
	1	 1			

