











































































































Original	Replacement	Original	Replacement
 Power	 Power	 CH+	 Ch +
 1	 1	 CH-	 Ch -
 2	 2	 Vol+	 Vol +
 3	 3	 Vol-	 Vol -
 4	 4	 I<< Skip	 I<<
 5	 5	 Skip >>I	 >>I
 6	 6	 << Slow/Search	 <<
 7	 7	 Slow/Search >>	 >>
 8	 8	 Pause	 Pause
 9	 9	 Stop	 Stop
 0	 0	 Play	 Play
 -/--	 GUIDE	 Menu/Play List	 Menu
 Cancel	 CLEAR EXIT	 Top Menu / Direct Navigator	 D. Menu
 AV	 TIMER AV	 Functions	 Options
 Input Select	 APP MEDIA	 Return	 Back
 Direct Tv Rec	 SEARCH TV/R	 Up	 Up
 ShowView	 ECO 3D	 Down	 Down





Original	Replacement
 Power	 Power
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 A	 Red
 B	 Green
 C	 Yellow

Original	Replacement
 D	 Blue

