







































































Original		Replacement		Original		Replacement	
	Standby		Power		EPG / D.Disp		Guide
	Eject		Eject		P+		Ch +
	1		1		P-		Ch -
	2		2		Up		Up
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Right		Right
	6		6		Down		Down
	7		7		LCD Menu		Menu
	8		8		Picture Format / DVD Setup		Format
	9		9		Picture Format / DVD Setup		Options
	0		0		Source		AV
	-/-- +10		Shift + Guide		PMode		Shift + Format
	Recall		Back		SMode		Shift + Dual
	V+		Vol +		Mute		Mute
	V-		Vol -		Play / Pause		Play
	Title / Lang		Dual		Play / Pause		Pause





Original		Replacement		Original		Replacement	
	Exit / Stop		Exit		Red / Program		Red
	Exit / Stop		Stop		Red / Program		Shift + 1
	Sleep		Sleep		Green / Menu		Green
	Nicam Audio		List		Green / Menu		D. Menu
	Text / <<		Text		Yellow / Repeat		Yellow
	Text / <<		<<		Yellow / Repeat		Shift + Text
	FAV Hold / >>		Pre Ch		Blue / AB		Blue
	FAV Hold / >>		>>				
	FAV- / Goto		Media				
	Fav+ / Angle		Smart				
	Index / I<<		Info				
	Index / I<<		I<<				
	Size / >>I		3D				
	Size / >>I		>>I				
	Reveal / Zoom		TV/R				
	Reveal / Zoom		Shift + Eject				
	Subpage /		Subt				



Subtitle