































































































































Original		Replacement		Original		Replacement	
	Power		Power		Mute		Mute
	Audio		Dual		Vol+		Vol +
	[+]		Format		Vol-		Vol -
	Digital		Media		[i+]		Info
	Analog		Smart		Menu/Home		Menu
	1		1		Return/Exit		Exit
	2		2		Return/Exit		Back
	3		3		CH+		Ch +
	4		4		CH-		Ch -
	5		5		Tools/Options		Options
	6		6		[:=]		Guide
	7		7				
	8		8				
	9		9				
	0		0				
	[≡]		Text				
	Recall		Pre Ch				





Original	Replacement	Original	Replacement
	Power		Power
	Menu		Menu
	Top Menu		D. Menu
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Clear		Exit
	Enter		Pre Ch
	F1		Smart
	F2		Media
	[: =]		Guide
	Display		Info
	Tools/Options		Options
	Return/Exit		Back
	Menu/Home		TV/R
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	I<<		I<<
	I>>		I>>
	Play		Play
	Pause		Pause




















Original	Replacement	Original	Replacement
	Stop		Stop
	<<		<<
	>>		>>
	↑		Ch -
	↓		Ch +














Original	Replacement
 Power	 Power
 Menu	 Menu
 Top Menu	 D. Menu
 F1	 Smart
 F2	 Media
 [:≡]	 Guide
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Enter	 Pre Ch

Original	Replacement
 Clear	 Exit
 Display	 Info
 Tools/Options	 Options
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 Return/Exit	 Back
 Menu/Home	 TV/R
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 >>	 >>









































































	Original	Replacement	Original	Replacement
	<<		<<	<<
	>>		>>	>>
	<<		<<	<<
	↑		CH -	Ch -
	↓		CH +	Ch +





























Original	Replacement	Original	Replacement
 Power	 Power	 Display	 Info
 Source	 AV	 Mute	 Mute
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	 Menu/Home	 Media
 4	 4	 Return/Exit	 Back
 5	 5	 Up	 Up
 6	 6	 OK	 Ok
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Play	 Play
 Clear	 Exit	 Stop	 Stop
 Enter	 Pre Ch	 Pause	 Pause
 Theatre	 Smart	 >>/Tuning+	 >>
 Sound Field	 Dual	 <</Tuning-	 <<
 AMP Menu	 Menu	 >>I/Preset+	 >>I





Original	Replacement	Original	Replacement
 I<</Preset-	 I<<		
 →	 Ch +		
 ←	 Ch -		
 DMPort	 Options		
 Video 1	 Shift + 1		
 Video 2	 Shift + 2		
 BD	 Shift + 3		
 DVD	 Shift + 4		
 SAT	 Shift + 5		
 TV	 Shift + 6		
 SA-CD/CD	 Shift + 7		
 Tuner	 Shift + 8		

