































































































































	Original	Replacement	Original	Replacement
				
	Power	Power	Mute	Mute
				
	Audio	Dual	Vol+	Vol +
				
	[+]	Format	Vol-	Vol -
				
	Digital	Media	[i+]	Info
				
	Analog	Smart	Menu/Home	Menu
				
	1	1	Return/Exit	Exit
				
	2	2	Return/Exit	Back
				
	3	3	CH+	Ch +
				
	4	4	CH-	Ch -
				
	5	5	Tools/Options	Options
				
	6	6	[:≡]	Guide
				
	7	7		
				
	8	8		
				
	9	9		
				
	0	0		
				
	[≡]	Text		
				
	Recall	Pre Ch		





Original	Replacement	Original	Replacement
	Power		Power
	Menu		Menu
	Top Menu		D. Menu
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Clear		Exit
	Enter		Pre Ch
	F1		Smart
	F2		Media
	[: =]		Guide
	Display		Info
	Tools/Options		Options
	Return/Exit		Back
	Menu/Home		TV/R
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	I<<		I<<
	>>I		>>I
	Play		Play
	Pause		Pause









































































	Original	Replacement	Original	Replacement
	Stop			
	<<			
	>>			
	Ch -			
	Ch +			















Original	Replacement	Original	Replacement
	Power		Power
	Menu		Menu
	Top Menu		D. Menu
	F1		Smart
	F2		Media
	[:=]		Guide
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Enter		Pre Ch
	Clear		Exit
	Display		Info
	Tools/Options		Options
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Return/Exit		Back
	Menu/Home		TV/R
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Play		Play
	Pause		Pause
	Stop		Stop
	>>		>>









































































	Original	Replacement	Original	Replacement
	<<		<<	
	>>		>>	
	<<		<<	
	↑		Ch -	
	→		Ch +	





Original		Replacement		Original		Replacement	
	Power		Power		Display		Info
	Source		AV		Mute		Mute
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		Menu/Home		Media
	4		4		Return/Exit		Back
	5		5		Up		Up
	6		6		OK		Ok
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		Play		Play
	Clear		Exit		Stop		Stop
	Enter		Pre Ch		Pause		Pause
	Theatre		Smart		>>/Tuning+		>>
	Sound Field		Dual		<</Tuning-		<<
	AMP Menu		Menu		>>I/Preset+		>>I





Original	Replacement	Original	Replacement
 I<</Preset-	 I<<		
	 Ch +		
	 Ch -		
 DMPort	 Options		
 Video	 Shift + 1		
 BD	 Shift + 3		
 DVD	 Shift + 4		
 SAT	 Shift + 5		
 TV	 Shift + 6		
 Tuner/Band	 Shift + 8		

