









	Original	Replacement	Original	Replacement
On/Off	On/Off	 Power		
Aux Input	AUX Input	 AV / Input / RDS		
Digital Input	Digital Input	 D.Menu / Top		
Stereo	Stereo	 Audio / Lang I/II		
Surround	Surround	 Eject / Surround		
Vol. +	Vol+	 Vol+		
Mute	Mute	 Mute / Dimmer		
Vol. -	Vol-	 Vol-		

