




Original	Replacement
 Power	 Power
 Colors	 Format
 Ambilight	 3D
 Pair/Sources	 AV
 ≡*/Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 ←	 Back
 Home	 Smart
 +	 Options
 <<	 <<
 ▶	 Play
 >>	 >>
 ■	 Stop

Original	Replacement
 Pause	 Pause
 Rec	 Rec
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Netflix	 Shift + Media
 Windows	 Media
 Rakuten Tv	 Shift + Smart
 P +	 Ch +
 P-	 Ch -
 TV/Exit	 Exit
 1	 1
 2	 2



