
































































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	[]		Smart
	[≡]		Text
	Input		AV
	Output		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	C		Pre Ch
	[*]		TV/R
	[↔*]		Subt
	[↑*]		Sleep
	[↑]		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[≡+]		3D
	[> <]		List
	Vol+		Vol +
	Vol-		Vol -
	Prog+		Ch +
	Prog-		Ch -
	[+]		Info
	SAT		Back


















Original	Replacement	Original	Replacement
	Picture		Format
	[+]		Eject
	♪		Dual
	Up/+		Up
	Down/-		Down
	←		Left
	Menu		Menu
	OK		Ok
	Power MDP		Shift + Power
	>> MDT		>>
	Play MDT		Play
	<< MDT		<<
	Stop MDT		Stop
	Pause MDT		Pause
	Prog+ MDT		Shift + Ch +
	Prog- MDT		Shift + Ch -


















	Original	Replacement	Original	Replacement
	Power			
	Prog+			
	Prog-			
	>>			
	Play			
	<<			
	Stop			
	Pause			
	Rec			





Original	Replacement	Original	Replacement
 Power	 Power		
 Prog+	 Ch +		
 Prog-	 Ch -		
 >>	 >>		
 Play	 Play		
 <<	 <<		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		





	Original	Replacement	Original	Replacement
	Power			
	Prog+			
	Prog-			
	>>			
	Play			
	<<			
	Stop			
	Pause			
	Rec			

