





























































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SAT		Smart
	Tv/R		TV/R
	Menu		Menu
	Exit		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	FAV		Pre Ch
	EPG		Guide
	V+		Vol +
	V-		Vol -
	Info		Info
	Audio		Dual
	Text		Text
	P+		Ch +
	P-		Ch -
	Red		Red
	RCL		Options
	Green/Pause		Green
	Yellow		Yellow









































































Original	Replacement	Original	Replacement
 SUB	 Subt		
 V.F	 3D		
 Blue	 Blue		
 Pause	 Pause		
 <I	 I<<		
 I>	 >>I		
 Rec	 Rec		
 Play	 Play		
 <<	 <<		
 >>	 >>		
 Stop	 Stop		



























Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SAT		Smart
	Tv/R		TV/R
	Menu		Menu
	Exit		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	FAV		Pre Ch
	EPG		Guide
	V+		Vol +
	V-		Vol -
	Info		Info
	Audio		Dual
	Text		Text
	P+		Ch +
	P-		Ch -
	Red		Red
	RCL		Options
	Green/Pause		Green
	Yellow		Yellow









































































Original	Replacement	Original	Replacement
 SUB	 Subt		
 V.F	 3D		
 Blue	 Blue		
 Pause	 Pause		
 <I	 I<<		
 I>	 >>I		
 Rec	 Rec		
 Play	 Play		
 <<	 <<		
 >>	 >>		
 Stop	 Stop		





Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SAT		Smart
	Tv/R		TV/R
	Menu		Menu
	Exit		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	FAV		Pre Ch
	EPG		Guide
	V+		Vol +
	V-		Vol -
	Info		Info
	Audio		Dual
	Text		Text
	P+		Ch +
	P-		Ch -
	Red		Red
	RCL		Options
	Green/Pause		Green
	Yellow		Yellow





Original	Replacement	Original	Replacement
SUB	Subt		
V.F	3D		
Blue	Blue		
Pause	Pause		
<I	I<<		
I>	>>I		
Rec	Rec		
Play	Play		
<<	<<		
>>	>>		
Stop	Stop		

